### デジタル指示調節計 SDC35/36 取扱説明書 設置編

このたびは山武製品をお買いあげいただきまことにありがとうございます。この製品を正しく安全にお使いいただくために、この取扱説明書を必ずお読みになり、理解したうえでお使いください。 本書は、いつもお手元においてご使用ください。

### 使用上の制限について

本製品は、一般機器での使用を前提に、開発・設計・製造されております。

とくに、下記のような安全性が必要とされる用途に使用する場合は、フェールセーフ設計、冗長設計 および 定期点検の実施など、システム・機器全体の安全に配慮していただいた上でご使用ください。

- ・人体保護を目的とした安全装置
- ・輸送機器の直接制御(走行停止など)
- ・航空機
- ・宇宙機器
- ・原子力機器 など

本製品の働きが直接人命に関る用途には使用しないでください。

### お願い

この取扱説明書は、本製品をお使いになる担当者のお手元に確実に届くようにお取りはからいください。

この取扱説明書の全部、または一部を無断で複写、または転載することを禁じます。この取扱説明書の内容を将来予告なしに変更することがあります。

この取扱説明書の内容については、万全を期しておりますが、万一ご不審な点や記入もれなどがありましたら、当社までお申し出ください。お客様が運用された結果につきましては、責任を負いかねる場合がございますので、ご了承ください。

### ©2003 Yamatake Corporation ALL RIGHTS RESERVED

本書は使用上の注意事項と取り付け・結線・PVレンジ種類・パラメーター覧・主な仕様などを説明したものです。詳しい取り扱い方法・設定方法などは、別冊の「詳細編」をご覧ください。

各種機能の操作については次の説明書があります。必要に応じてお読み ください

デジタル指示調節計 SDC35/36 取扱説明書 詳細編 CP-SP-1150 デジタル指示調節計 SDC15/25/26/35/36用スマートローダパッケージ SLP-C35 取扱説明書 CP-UM-5290

デジタル指示調節計 SDC35/36 キー操作ダイジェスト CP-SP-1203 これらの資料は http://www.compoclub.com からダウンロードすることもできます。

### 確認してください

お買い上げいただいたSDC35/36は次のものが同梱されています。

取付器具 81409654-001 2個 取扱説明書(本書) CP-UM-5289JE 1部

### 安全上の注意

⚠ 警告

取り扱いを誤った場合に、使用者が死亡または重傷を負う危険の状態が生じることが 想定される場合。

⚠ 注意

取り扱いを誤った場合に、使用者が軽傷を負うか、または物的損害のみが発生する危険の状態か生じることが想定される場合。

### ▲ 警告

● 本器への通電前に配線が正しく行われていることを必ず確認してください。

本器への配線間違いは故障の原因になり、また危険な災害を招く 原因にもなります。

- 電源端子などの充電部には触らないでください。感電の恐れがあります。
- 🕟 本器を分解しないでください。感電・故障の恐れがあります。

### ⚠ 注意

- → 本器は、仕様に記載された使用条件(温度、湿度、電圧、振動、衝撃、取り付け方向、雰囲気など)の範囲内で使用してください。
  火災・故障の恐れがあります。
- 本器の通風穴をふさがないでください。 火災・故障の恐れがあります。
- 本器への結線は定められた基準に従い、指定された電源、および施工方法で正しく配線してください。 火災・感電・故障の恐れがあります。
- 本器ケース内部に線くず、切り粉、水などが入らないようにしてください。火災・故障の恐れがあります。
- 端子ねじは仕様に記載されたトルクで確実に締め付けてください締め付けが不完全だと感電・火災の恐れがあります。
- 本器の未使用端子を中継端子として使用しないでください。 感電・火災・故障の恐れがあります。
- ◆ 本器の結線後は端子カバーを取り付けることをお勧めします。 ・ 感電の恐れがあります。(本器は別売品の端子カバーを用意しています)
- ◆ 本器のリレーは仕様に記載された寿命の範囲内で使用してください そのまま、使い続けると火災、故障の恐れがあります。
- 雷サージの恐れのある場合は、当社製サージノンを使用してください 火災・故障の恐れがあります。

### 設置

### ■ 取付場所

本器を取り付けるときは、次のような所に設置してください。

- ・供給電源およびリレー接点出力を除く入出力のコモンモード電 圧:対大地間の電圧は、33Vr.m.s.以下、46.7Vピーク以下、 DC70V以下としてください。
- ・高温、低温、高湿度、低湿度にならない所
- ・硫化ガスなど腐食性ガスのない所
- ・粉じん、油煙などの少ない所
- ・直射日光および風雨の当たらないように適切な処理のされた所
- ・機械的振動、衝撃の少ない所
- ・高圧線の下、溶接機の近くおよび電気的ノイズの発生源の近くでない所
- ・ボイラなどのような高圧点火装置から15m以上離れた所
- ・電磁界の影響の少ない所
- ・可燃性の液体や蒸気のない所


#### ■ 取付方法

- ・取り付け角度は水平位置から、後下がり10度以内、後上がり10度 以内としてください。
- ・パネルは板厚9mm以下で剛性のあるものをご使用ください。


### ■ 外形寸法

C35

(単位:mm)



● C36 (単位:mm)




### ! 取扱い上の注意

付属の取付器具のねじを締めて、取付器具が動かなくなったガタのない状態からさらに1回転だけねじを回してパネルに固定してください。


ねじを締めすぎるとケースを変形させてしまいます。

#### ● パネル穴あけ図

· C35



· C36



### ■ 取扱い上の注意

・3台以上横密着取り付けする場合、周囲温度は40℃を超えないようにしてください。

### 結 線

本器を操作される方の手が届く範囲内に、この製品の主電源遮断用のス イッチを必ず設けてください。

また、AC電源モデルの本器の電源配線には遅動タイプ(T)の定格電流 0.5A、定格電圧250Vのヒューズを設けてください。(IEC127) 本器側面の端子配列ラベルで使用している記号の意味は下表のとおりです。


記号	内 容
~	交流
===	直流
A	注意、感電の危険
$\triangle$	注意

### !! 取扱い上の注意


- ・ 結線は形番と端子番号を本体側面のラベルで確認してから行ない、必ず間違いのないことを確認してください。
- ・ 端子の接続にはM3のねじに適合する圧着端子を使ってください。
- ・ 入出力信号線は動力線や電源線から50cm以上離してください。また、同一の配線管やダクト内を通さないでください。 ・ 圧着端子などが隣の端子と接触しないようにしてください。
- ・カレントトランスにはヒータ電流の流れる導線を貫通させてください。また、ヒータ電流は仕様に記載した許容電流を超えて使用しないでください。本器を破損することがあります。
- ・ カレントトランス入力は位相制御に使用できません。

- ・制御出力1と制御出力2の間はアイソレーションされていません。必要に応じてアイソレータを使用してください。
- せん。必要に応じてアイソレータを使用してください。 ・RS-485の通信路の両端に終端抵抗をつけないでください。
- 通信できなくなります。
  ・モータ駆動リレー出力に接続するモータ電源がAC100V、
- 200Vの場合、外部に補助リレーを使用してください。
  ・モータ駆動端子③、⑭、⑮とMFB入力端子⑦、⑧、⑨は、同一ダクト内に配線したり、6心ケーブルで配線しないでください。モータ起動時のノイズなどで本器の故障の原因になり
- ・ 本器に接続する機器または装置は、本器の電源、入出力部の 最高使用電圧に適した基礎絶縁が施されているものを使用し てください。
- 本器は電源投入後、安定のため最大5秒間は機能しないようになっています。その後運転状態に入りますが、規定の精度を満足させるためには、ウォームアップ時間が30分以上必要です。

#### 結線




● 入出力間アイソレーション 実線で囲まれたものは他の信号と絶縁されています。



入出力の有無は形番によります。

(注1) 独立接点の場合、イベント出力1とイベント出力2の間はア イソレーションされています。

### 各部の名称と機能



① 第1表示部 ② 第2表示部 : PV値(現在の温度など)や設定項目を表示します。

: SP値(設定温度など)や各設定項目の設定値を表示し ます。第2表示部がSPを表示しているときは、spが 点灯し、操作量(MV)を表示しているときは、outが

点灯します。

: MANUALモード(手動)のとき点灯します。 ③ モード表示灯 man

rsp : RSP(リモート設定入力)モードのとき点灯します。 ev1~ev3:イベントリレー出力がONしているとき点灯し

ot1・ot2:制御出力がONしているとき点灯します。

④ マルチステータス表示灯 :点灯条件と点灯状態を組みにして、優先度のついた3組を設定できます。

⑤ [mode] +-:1秒以上押し続けると、あらかじめ設定してある操作

ができます。 :運転表示で表示内容を切り替えます。バンク設定表

⑥ [display] ‡ −

示から運転表示に戻します

:数値の増減、桁送りに使用します。 ⑦ <、 ∨、 ∧キー

⊗ [para] + − 表示の切り替えをします

設定の変更開始と変更中の数値の確定を行います。 9 [enter] + − : スマートローダパッケージに同梱されている専用ケーブルを使用してパソコンと接続します。 ① ローダコネクタ

### PVレンジ表

C01	センサ	レンジ	_C01	センサ	レンジ
設定値	タイプ		設定値	タイプ	
1	K	-200~+1200°C	41	Pt100	-200.0~+500.0°C
2	K	0~1200℃	42	JPt100	-200.0~+500.0°C
3	K	0.0∼800.0℃	43	Pt100	-200.0∼+200.0℃
4	K	0.0∼600.0℃	44	JPt100	-200.0∼+200.0℃
5	K	0.0∼400.0℃	45	Pt100	-100.0∼+300.0℃
6	K	-200.0~+400.0°C	46	JPt100	-100.0∼+300.0℃
7	K	-200.0∼+200.0°C	47	Pt100	-100.0∼+200.0℃
8	J	0~1200℃	48	JPt100	-100.0∼+200.0℃
9	J	0.0∼800.0℃	49	Pt100	-100.0~+150.0℃
10	J	0.0∼600.0℃	50	JPt100	-100.0~+150.0℃
11	J	-200.0~+400.0°C	51	Pt100	-50.0~+200.0°C
12	Е	0.0∼800.0℃	52	JPt100	-50.0~+200.0°C
13	Е	0.0∼600.0℃	53	Pt100	-50.0~+100.0°C
14	T	-200.0~+400.0°C	54	JPt100	-50.0~+100.0°C
15	R	0~1600℃	55	Pt100	-60.0~+40.0°C
16	S	0~1600℃	56	JPt100	-60.0∼+40.0°C
17	В	0~1800℃	57	Pt100	-40.0~+60.0°C
18	N	0~1300℃	58	JPt100	-40.0~+60.0°C
19	PL II	0~1300℃	59	Pt100	-10.00~+60.00°C
20	WRe5-26	0~1400℃	60	JPt100	-10.00~+60.00°C
21	WRe5-26	0~2300℃	61	Pt100	0.0∼100.0℃
22	Ni-NiMo	0~1300℃	62	JPt100	0.0∼100.0℃
23	PR40-20	0~1900℃	63	Pt100	0.0~200.0℃
24	DIN U	-200.0~+400.0°C	64	JPt100	0.0∼200.0℃
25	DIN L	-100.0∼+800.0°C	65	Pt100	0.0∼300.0℃
26	金鉄	0.0K~360.0K	66	JPt100	0.0∼300.0℃
	クロメル		67	Pt100	0.0∼500.0℃
			68	JPt100	0.0∼500.0℃

レンジ

83 0~100mV 小数点位置可変

84 0~1V 86 1~5V 87 0~5V

88 0~10V

90 4~20mA

0~20mA

### ! 取扱い上の注意

 ・ 精度は±0.1%FS±1digit 熱電対の 負の領域は±0.2%FS±1digitです。 ただし、レンジにより異なります。
 81 0~10mV -1999~+9999の範囲で スケーリング No.17 (センサタイプB) は、 260°C以下: ±4.0%FS、

260~800℃: ±0.4%FS 800~1800℃: ±0.2%FS 20℃未満は表示されません。

No.15 (センサタイプR)、 No.16 (センサタイプS) は、 100℃以下: ±0.2%FS、

100~1600℃:±0.15%FS No.23 (センサタイプPR40-20) は、

0~300°C: ±2.5%FS、300~800°C: ±1.5%FS、

800~1900°C : ±0.5%FS


No.26 (センサタイプ金鉄クロメル) は、土1.5Kとなります。

No.55~62 (センサタイプPt100またはJPt100)、 No.81 (センサタイプ0~10mV) は±0.15%FS±1digit

・小数点表示のあるレンジは、小数点以下の桁を表示します。

### 設定操作

キー操作のフローを示します。



この図に書いてある表示や設定の状態は、説明のための例です。 実際には形番や設定内容により表示しない表示や設定があります。

データの設定方法には、標準タイプと特殊タイプがあります。ここでは 標準タイプで説明しています。

#### ● PVレンジ種類の設定例

セットアップバンク(SEUP)のバンク設定表示で第1表示部にCOIを表 示させてください。

[enter]キーを押すと、第2表示部がフラッシング (点滅) します。 [<][∨][∧]キーで桁の移動や値の増減をしてください。 希望の数値で[enter]キーを押すと、フラッシングが終了し、データ が確定します

#### ● SP1の設定例

SPバンク(5P)のバンク設定表示で第1表示部に5P・1を表示させてく ださい。

[enter]キーを押すと、第2表示部がフラッシング (点滅) します。 [<][∨][∧]キーで桁の移動や値の増減をしてください。 希望の数値で[enter]キーを押すと、フラッシングが終了し、データ が確定します

取り扱い方法、設定方法の詳細は、別冊の

SDC35/36「キー操作ダイジェスト」CP-SP-1203 をご覧ください。

### アラームコード一覧表

土田田舎吐のコニ ノ まニル 昇炊ナニュナナ

本器異常時のアラーム表示と対策を示します。					
アラームコード	異常名称	原因	処 置		
RLO (	PV入力異常 (オーバレンジ)	センサ断線、誤配線 PVレンジ種類誤設定	配線の確認 PVレンジ種類の再設定		
RLO2	PV入力異常 (アンダーレンジ)	センサ断線、誤配線 PVレンジ種類誤設定			
RLO3	CJ異常 PV入力異常	端子温度異常 (熱電対) センサ断線、誤配線 (測温抵抗体)	周囲温度の確認 配線の確認		
RLOS	RSP入力異常 (オーバーレンジ) (RSPモード時のみ表示)	センサ断線、誤配線 RSPレンジ種類誤設定	配線の確認 RSPレンジ種類の再設定		
RLO6	RSP入力異常 (アンダーレンジ) (RSPモード時のみ表示)	センサ断線、誤配線 RSPレンジ種類誤設定	配線の確認 RSPレンジ種類の再設定		
RL07	MFB入力異常	断線、誤配線	配線の確認 MFB入力値の確認		
RL 10	モータ調整異常	断線、誤配線モータ電源断	配線の確認、モータ電源 の確認 再調整		
RLII	CT入力異常 (オーバーレンジ) (CT入力1/2の片方または 両方)	表示範囲上限を超える電流 を測定、CTターン 数誤設定、CT電力線貫通回 数誤設定、誤配線	表示範囲に合ったターン 数のCT使用 CTターン数の再設定 CT電力線貫通回数の再設定 配線の確認		
AL70	A/D変換異常	A/D変換部故障	本体交換		
RL95	パラメータ異常	データ確定中に電源断 ノイズなどでデータ破壊	・電源再投入 ・データの再設定		
RL95	調整データ異常	データ確定中に電源断 ノイズなどでデータ破壊	(AL95/97は設定データ、 AL96/98は調整データ)		
RL97	パラメータ異常 (RAM領域)	ノイズなどでデータ破壊	・本体交換		
RL98	調整データ異常 (RAM領域)	ノイズなどでデータ破壊			
RL99	ROM異常	ROM(メモリ)故障	・電源再投入 ・本体交換		

### 保守

清 掃 : 計器の汚れを取る場合は、柔らかい布での乾拭きを行

ってください。

部品交換 : 部品交換は、おやめください。

ヒューズ交換 :AC電源モデルで電源配線に設けたヒューズを交換す るときは、必ず指定の規格品を使用してください。

規格 IEC127、遮断速度 遅動タイプ (T)、

定格電圧 250V、定格電流 0.5A

### 形番構成表

基本 取り 形番 付け	制御出力	PV 入力	電源	オブション 1	オプション 2		追加 処理2	仕	様	備考
C35	1177	7173	$\vdash$	<del>                                     </del>	$\overline{}$	~=:	~-12	マスクサイズ48mm>	(96mm	$\vdash$
C36								マスクサイズ96mm>		
T	$\overline{}$		$\overline{}$	$\vdash$	$\overline{}$			パネル取付形		-
	-	-	$\overline{}$	$\vdash$	-	-	-	制御出力1	制御出力2	-
	R0							リレー出力 NO	リレー出力 NC	
(注3)	R1								モータ駆動リレー出力	MFB
()			l					OPEN側	CLOSE側	付き
	V0							電圧パルス出力 (SSR駆動用)	なし	
	VC							電圧パルス出力 (SSR駆動用)	電流出力	
	VD							電圧パルス出力 (SSR駆動用)	連続電圧出力	
	VV		l					電圧パルス出力	電圧パルス出力	
								(SSR駆動用)	(SSR駆動用)	$\perp$
	C0							電流出力	なし	
	CC							電流出力	電流出力	
	CD							電流出力	連続電圧出力	
	D0							連続電圧出力	なし	$\Box$
	DD				$ldsymbol{ld}}}}}}$			連続電圧出力	連続電圧出力	Ш
		U						ユニバーサル		
			Α					AC電源(AC100~240		$\Box$
			D		$oxed{oxed}$		$oxed{oxed}$	DC電源(AC24V/DC24	,	Ш
				1				イベントリレー出力3		
				2					点、補助出力(電流出力)	
				3					点、補助出力(電圧出力)	$\perp$
			注3)	4				イベントリレー出力2		
		(7	注3)	5				イベントリレー出力2	!点(独立接点)、	
			. <del></del>			$\vdash$	$\vdash$	補助出力(電流出力) イベントリレー出力2	上 /X4 → 4→ 上 \	$\vdash$
		()	注3)	6				補助出力(電圧出力)	点(独立接点)、	
					0	$\vdash$	$\vdash$	なし	o E = 200 E # 7 J + E	$\vdash$
				、2)	1	-	$\vdash$		2点、デジタル入力4点	
			`	、2)	2			RS-485通信	2点、デジタル入力4点、	
			`	、2)	3			RSP入力	2点、デジタル入力2点、	
			(注 1	、2)	4			RSP入力、RS-485通信	2点、デジタル入力2点、	
						0	$\vdash$	追加処理なし		$\Box$
						D	$\vdash$	検査成績書添付		
						Т		熱帯処理品		
(注1)カレ	ントト	・ラン	スは	別売り	です。	K	$ldsymbol{ldsymbol{ldsymbol{eta}}}$	硫化対策処理品		
(注2)制御						В		熱帯処理品+検査成績		
, , , , , , , , , , , , , , , , , , ,	ランフ	スカカ	はつ	きませ	h.	L	$oxed{oxed}$	硫化対策処理品+検査		$oxed{oxed}$
	入力に				-	Υ		トレーサビリティ証明	月対応 -	
(注3) DC電	電源で	は選払	尺でき	ません	L0		0	IP65構造対応なし		
										_

### 仕 様

● PV入力

熱雷対

: K、J、E、T、R、S、B、N(JIS C 1602-1995) PL II(Engelhard Industries資料(ITS90))

WRe5-26(ASTM E988-96(Reapproved 2002)) Ni-NiMo (ASTM E1751-00) PR40-20(Johnson Matthey資料)

DIN U, DIN L(DIN 43710-1985) 金鉄クロメル(林電工資料)

測温抵抗体 Pt100(JIS C 1604-1997) IPt100(IIS C 1604-1989)

直流電圧  $0 \sim 10 \text{mV}, -10 \sim +10 \text{mV}, 0 \sim 100 \text{mV}, 0 \sim 1V, 1 \sim 5V$ 

0~5V, 0~10V : 0~20mA、4~20mA

サンプリング周期 :100ms

: 100ms : ±0.1%FS±1digit、熱電対の負の領域は±0.2%FS±1digit (周囲温度23±2℃にて) 指示精度

冷接点補償精度 : ±0.5℃(周囲温度23±2℃にて) ±1.0℃(周囲温度15~35℃にて)

±1.5℃(周囲温度0~15、35~50℃にて) 冷接点補償方法 : 計器内にて補償、および計器外での補償(0℃のみ)選択可能

● 外部接点入力

:無電圧接点またはオープンコレクタ

許容ON接点抵抗 :250Ω以下 許容OFF接点抵抗 : 100kΩ以上 許容ON残留電圧 : 1.0V以下

ON時端子電流 : 約7.5mA(短絡時)、約5.0mA(接点抵抗250Ω時)

最小ホールド時間 : 200ms以上

カレントトランス入力 

点数 入力対象 :カレントトランス 巻数100~4000ターン

(100ターン単位で対応) 別売品 形番(QN206A(800ターン、穴径5.8mm)) 別売品 形番(QN212A(800ターン、穴径12mm)) : AC0.4A(800ターン、電力線貫通回数1にて)

計測電流下限

計算式(ターン数÷(2000×電力線貫通回数))

: AC50.0A(800ターン、電力線貫通回数1にて) 計算式(ターン数÷(16×電力線貫通回数)) 計測電流上限 許容計測電流 : AC 70.0A以下(800ターン、電力線貫通回数1にて)

計算式(ターン数÷(16×電力線貫通回数)×1.4)

表示範囲下限 AC0.0A

: AC70.0A(800ターン、電力線貫通回数1にて) 表示範囲上限 計算式(ターン数÷(16×電力線貫通回数)×1.4)

表示精度 表示分解能 AC0.1A

● モータフィードバックポテンショメータ入力(R1モデル)

: 100~2500 Ω 許容抵抗値 : AL07表示 新線検出

● RSP入力

: リニア0~20mA/4~20mA または リニア0~5V/1~5V/0~10V 入力種類

サンプリング周期 : 100ms

指示精度 : ±0.1%FS±1digit (周囲温度23±2℃にて)

入力断線時動作 :ダウンスケール+AL06

● 制御出力 リレー出力

: NO側AC250V/DC30V、3A(抵抗負荷) 接点定格 NC側AC250V/DC30V、1A(抵抗負荷)

NO側5万回以上、NC側10万回以上 最小開閉仕様 : 5V. 100mA 最小開時間/閉時間:250ms

・モータ駆動リレー出力(R1モデル)

接点定格 AC250V、8A(抵抗負荷) 12万回以上 最小開閉仕様 : DC24V 40mA

・電圧パルス出力(SSR駆動用) 開放時端子間電圧 : DC19V±15% : 82Ω±0.5% : DC24mA以下 内部抵抗 許容電流

最小OFF時間/ON時間 : 時間比例周期10s未満のとき1ms 時間比例周期10s以上のとき250ms

・電流出力 出力形式 : DC0~20mAまたは4~20mA電流出力

許容負荷抵抗 :6000以下

: ±0.1%FS(周囲温度23±2℃にて)ただし0~1mAは±1%FS 出力精度 · 電圧出力 出力形式 : DC0~5V/1~5Vまたは0~10V電圧出力

許容負荷抵抗 : 1000 Q D/F

出力精度 : ±0.1%FS(周囲温度23±2℃にて)ただし0~0.05Vは±1%FS

● 補助出力 電流出力

: DC0~20mAまたは4~20mA電流出力 出力形式

許容負荷抵抗 :600 Ω以下 : ±0.1%FS(周囲温度23±2℃にて) 出力精度

ただし0~1mAは±1%FS · 電圧出力

出力形式 : DC0~5V/1~5Vまたは0~10V電圧出力 許容負荷抵抗 : 1000 Ω以上

±0.1%FS(周囲温度23±2℃にて)ただし0~0.05Vは±1%FS 出力精度

● イベントリレー出力(ev1~ev3)

: AC250V/DC30V 2A(抵抗負荷) : 10万回以上 接点定格

最小開閉仕様 :5V、10mA(参考值)

● RS-485通信 伝送路 3線式

4800, 9600, 19200, 38400bps 伝送速度

通信プロトコル : CPL、MODBUS準拠

終端抵抗 :接続禁止

● 環境条件

質量

動作条件 周囲温度

:0~50℃(密着取り付けの場合は0~40℃)

10~90%RH(結露なきこと)

: 10 - 30/JAII(報路などと) : AC電源モデル AC100~240V 50/60Hz DC電源モデル AC24V 50/60Hz、DC24V : AC電源モデル AC85~264V 50/60±2Hz 定格電源電圧 電源電圧範囲

DC電源モデル AC21.6~26.4V 50/60±2Hz、 DC21.6~26.4V

輸送条件 : -20~+70°C 周用温度

: 10~95%RH(結露なきこと) 周囲湿度 ● その他仕様

: AC電源モデル 12VA以下 DC電源モデル 12VA以下(AC24V) 8W以下(DC24V) 消費電力

停電不感時間 :AC電源モデル 20ms以下 DC電源モデル 停電なきこと

喜度 : 2000 m 以下

: C35 48×96 約250g(専用取付器具含む) C36 96×96 約300g(専用取付器具含む)

端子ねじ締付トルク: 0.4~0.6N·m以下

EN61010-1, EN61326 適合規格 過電圧カテゴリ : CategoryII(IEC60364-4-443、IEC60664-1)

許容汚染度 : Pollution degree2

### 付属品・オプション部品一覧表

名 称	形番
取付器具	81409654-001(付属品)
カレントトランス	QN206A(穴径5.8mm)
	QN212A(穴径12mm)
ハードカバー	81446915-001(C35用)
	81446916-001(C36用)
ソフトカバー	81441121-001(C35用)
	81441122-001(C36用)
端子カバー	81446912-001(C35用)
	81446913-001(C36用)

### SDC35/36パラメーター覧表

### 【運転表示一覧表】

### ■ 運転表示

表示	項目	内 容	初期値	表 示 レベル
第1表示:PV 第2表示:SP	SP (目標値)	SPリミット下限(C07)~ SPリミット上限 (C08)	0	0
L5P (表示例)	LSP組番号	1~LSP使用組数 (C30、最大8)	1	0
第2表示:LSP	(第1桁=最右桁の数値)			
5と. :- (表示例) ステップ番号	ステップ運転残り時間	設定不可	-	0
ステッノ番号 第2表示:		第1表示: 「St.」の横にステップ番号と、上昇ランプ、下降ランプ、ソーク		
		の区別を表示		
時間		第2表示:ステップ運転時間単位 (C33)		
		に従った単位 (0.1s、min. s、h. minの		
		どれか) で表示		
第1表示:PV	MV(操作量)	-10.0~+110.0%	-	0
第2表示:MV		AUTOモードで設定不可 (数値の点滅なし)		
		(数値の点滅なし)   MANUALモードで設定可能		
		(数値の点滅あり)		
HERE	加熱MV (操作量)	設定不可	_	0
Cook	冷却MV (操作量)	-10.0~+110.0%	_	0
Fb	MFB (モータ開度フィード	設定不可	-	0
	バック値)	-10.0~十110.0%		
第1表示:PV	AT進捗	推定の場合、0.0~100.0%で点滅表示 設定不可		0
ЯĿ! (表示例)	(第1桁=最右桁の数値)	1~:AT起動中(値が減っていく)		"
712 ((307)(73)	(N) (III NX III II V XX III )	0:AT終了		
CEI	CT(カレントトランス)入力1	設定不可	_	0
CFS	電流値	設定不可		0
Lec	CT(カレントトランス)入力2 電流値		_	"
Εl	内部イベント1主設定	内部イベント動作種類により設定可能な	0	0
E 1. 5b	内部イベント1副設定	範囲が異なる	0	0
		-1999~十9999U:下記以外の場合		
		0~9999U:設定値が絶対値の場合		
£1	タイマ残り時間1	-199.9~十999.9%:MVの場合 設定不可		0
(表示例)	> 1 ₹7X.7/ P(T H) 1	就足116    第1表示:「t1.」の横にONディレイ、		"
(3(7)(7))		OFFディレイの区別を表示		
		第2表示:内部イベント1ディレイ時間		
		単位 (E1.C3の3桁目) に従った単位		
	1 40 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	(0.1s、s、minのどれか) で表示		
E2	内部イベント2主設定	内部イベント動作種類により設定可能な 範囲が異なる	0	0
E2. 5b	内部イベント2副設定	郵囲が異なる   一1999~十9999U:下記以外の場合	0	0
	THE PARTY OF THE P	0~9999U:設定値が絶対値の場合		
		-199.9~+999.9%:MVの場合		
£2	タイマ残り時間2	設定不可		0
(表示例)		第1表示:「t2.」の横にONディレイ、		
		OFFディレイの区別を表示 第2表示:内部イベント2ディレイ時間		
		第2級小・内部1ハンド2万1 レ1時間 単位 (E2.C3の3桁目)に従った単位		
		(0.1s、s、minのどれか) で表示		
E3	内部イベント3主設定	内部イベント動作種類により設定可能	0	0
		な範囲が異なる		
E3. Sb	内部イベント3副設定	-1999~十9999U: 下記以外の場合	0	0
		0~9999U:設定値が絶対値の場合 -199.9~+999.9%:MVの場合		
£3	タイマ残り時間3	- 199.9~十999.9% · MVの場合 設定不可	<del>  </del>	0
(表示例)	2 1 1 7 A 7 RVIRIO	第1表示: 「t3.」の横にONディレイ、		
l`,		OFFディレイの区別を表示		
		第2表示:内部イベント3ディレイ時間		
		単位 (E3.C3の3桁目) に従った単位		
		(0.1s、s、minのどれか) で表示		

### 【パラメータ設定表示一覧表】

### ■ モードバンク バンク選択:ñod£

表示	項目	内 容	初期値	表 示 レベル
Rñ	AUTO/MANUAL E - F	<i>RUEo</i> : AUTO(自動)モード ŏ8o: MANUAL(手動)モード	AUTO	0
rr	切り替え RUN/READYモード切り替え		RUN	0
Lr	LSP/RSPモード切り替え		LSP	0
RŁ	AT停止/起動切替え	Rと. oF:AT停止 Rと. on:AT起動	AT停止	0
do.Lt	全DOラッチ解除	Lt. on: ラッチ継続 Lt. oF: ラッチ解除	ラッチ 継 続	0
C. dl l	通信DI1	di. of : OFF di. on : ON	OFF	0

### ■ SPバンク バンク選択:5*P*

表示	項目	内 容	初期値	表示
	^ -		1337431	レベル
r5P	RSP	設定不可	_	0
Pld. r	PID組番号 (RSP用)	1~8	1	1
5P-1 ~	LSP1~8組のSP	SPリミット下限 (C07) ~		
5P-8		SPリミット上限 (C08)	0	0
Pld. 1 ~	PID組番号 (LSP1~8用)	1~8	1	1
Pld. 8				
rñ₽.1 ~	勾配 (LSP1~8用)	0~9999 (小数点位置はPVの小数点	0	1
rñP. 8		位置とSPランプ単位で決まる)		
Łiā. 1 ∼	時間 (LSP1~8用)	0.0~999.9 (ステップ運転時間単位が	0	1
₽ñ. 8		0.1sの場合)		
		0~9999 (ステップ運転時間単位が1s		
		また(t1minの場合)		

表示レベルの意味 0:簡単・標準・多機能で表示、

1:標準・多機能で表示、

2:多機能で表示

初期値は形番により変わるものがあります。

### ■ イベントバンク バンク選択: & J

表示	項目	内 容	初期値	表 示 レベル
E! ~ E8	内部イベント1~8 主設定	-1999~十9999 小数点位置は内部イベント動作種類に	0	0
E 1. 5b ~ E8. 5b	内部イベント1~8 副設定	合うように変わります 一部の動作種類では、0~9999となり ます	0	0
E 1, MY ~ E8, MY	内部イベント1~8 ヒステリシス	0~9999 小数点位置は内部イベント動作種類に 合うように変わります	5	0
E1. on ~ E8. on	内部イベント1~8 ONディレイ	0.0~999.9 (ディレイ時間単位0.1sの場合)	0	2
E 1. oF ~ E8. oE	内部イベント1~8 OFFディレイ	0~9999 (ディレイ時間単位0.1s以外の場合)	0	2

### ■ PIDバンク バンク選択:*Pld*

表示	項目	内 容	初期値	表 示 レベル
P-1 ~ P-8	比例帯 (PID1~8組)	0.1~999.9%	5.0	0
1-1 ~ 1-8	積分時間 (PID1~8組)	0~9999sまたは0.0~999.9s (0で積分動作なし)	120	0
d-1 ~ d-8	微分時間 (PID1~8組)	0~9999sまたは0.0~999.9s (0で微分動作なし)	30	0
rE-1 ~ rE-8	マニュアルリセット (PID1~8組)	-10.0~+110.0%	50.0	0
ol-1 ~ ol-8	操作量下限 (PID1~8組)	-10.0~+110.0%	0.0	1
oH-1 ∼ oH-8	操作量上限 (PID1~8組)	-10.0~+110.0%	100.0	1
P-16 ~ P-86	冷却側比例帯 (PID1~8組)	0.1~999.9%	5.0	0
1-16 ~ 1-86	冷却側積分時間 (PID1~8組)	0~9999sまたは0.0~999.9s (0で積分動作なし)	120	0
d-16 ~ d-86	冷却側微分時間 (PID1~8組)	0~9999sまたは0.0~999.9s (0で微分動作なし)	30	0
oL16 ~ oL86	冷却側操作量下限 (PID1~8組)	-10.0~+110.0%	0.0	1
оН.1С ~ оН.8С	冷却側操作量上限 (PID1~8組)	-10.0~+110.0%	100.0	1

### ■ パラメータバンク バンク選択:*PR-R*

表示	項目	内 容	初期値	表 示レベル
CtrL	制御方式	0:ON/OFF制御	0.	0
		1:PID固定	または1	
Rt. ol	AT時操作量下限	-10.0~+110.0%	0.0	0
Rt. oH	AT時操作量上限	-10.0~+110.0%	100.0	0
dIFF	ON/OFF制御ディファレンシャル	0~9999U	5	0
oFF5	ON/OFF制御動作点オフセット	-1999~+9999U	0	2
FL	PVフィルタ	0.0~120.0s	0.0	0
r R	PVレシオ	0.001~9.999	1.000	1
ы	PVバイアス	-1999~+9999U	0	0
FLE	RSPフィルタ	0.0~120.0s	0.0	0
rR2	RSPレシオ	0.001~9.999	1.000	1
b/2	RSPバイアス	-1999~+9999U	0	0
CYU	時間比例単位1	0:1s単位	0	2
		1:0.5s固定 (サイクルタイム設定不可)		
		2:0.2s固定 (サイクルタイム設定不可)		
		3:0.1s固定 (サイクルタイム設定不可)		
CY	時間比例周期1	5~120s (出力にリレー出力を含む場合)	10、	0
		1~120s (出力にリレー出力を含まない場合)	または2	
CANS	時間比例単位2	0:1s単位	0	2
		1:0.5s固定 (サイクルタイム設定不可)		
		2:0.2s固定 (サイクルタイム設定不可)		
		3:0.1s固定 (サイクルタイム設定不可)		
CAS	時間比例周期2	5~120s (出力にリレー出力を含む場合)	10、	0
		1~120s (出力にリレー出力を含まない場合)	または2	
<i>ե</i> թ. <i>Է</i> ሃ	時間比例動作種類	0:制御性重視型	0、	2
		1:操作端寿命重視型 (時間比例周期内	または1	
		では1回だけのON/OFF動作)		
oUEL	操作量変化リミット	0.0~999.9%/s	0.0	2
		(0.0はリミットなし)		
SPU	SPランプ上昇勾配	0.0~999.9U	0.0	2
SPd	SPランプ下降勾配	(0.0Uは勾配なし)	0.0	2

### ■ 拡張調整バンク バンク選択: Et

表示	項目	内 容	初期值	表 示 レベル
RE. EY	AT種類	0:通常(標準的な制御特性) 1:即応(外乱に速やかに反応する制御 特性) 2:安定(PVの上下動が少ない制御 特性)	1	0
dF. bd	JF整定幅	0.00~10.00	0.30	2
5P. LS	SPラグ定数	0.0~999.9	0.0	2
RE-P	AT時比例帯調整係数	0.00~99.99	1.00	2
RE-I	AT時積分時間調整係数	0.00~99.99	1.00	2
Rt-d	AT時微分時間調整係数	0.00~99.99	1.00	2
Ctr. A	制御アルゴリズム	0:PID (従来型PID) 1:Ra-PID (高性能型PID)	0	1
dF. ou	JFオーバーシュート抑制係数	0~100	0	1

### ■ ゾーンバンク バンク選択:*≧on€*

表示	項目	内 容	初期值	表 示 レベル	備考
2n-1	ゾーン1	-1999~+9999U	9999U	2	ゾーンPID動作選択
20-5	ゾーン2		9999U	2	を使用する
2n-3	ゾーン3		9999U	2	(C24≠0) の場合、
2n-4	ゾーン4		9999U	2	表示
2n-5	ゾーン5		9999U	2	
Zn-6	ゾーン6		9999U	2	
2n-7	ゾーン7		9999U	2	
Zn.dF	ゾーン用ヒステリシス	0~9999	5U	2	

### 【セットアップ設定表示一覧表】

#### ■ セットアップバンク バンク選択:5kUP

表示	項目	内 容	初期値	表え
01	PVレンジ種類	 熱電対のレンジ:1~26	88	0
	1 VVン ノ1主形	測温抵抗体のレンジ:41~68	00	"
		直流電圧・直流電流のレンジ: 81~84、86~90		
502	温度単位	0:摂氏 (℃)	0	0
		1:華氏 (°F)		
03	冷接点補償	0:冷接点補償を行う (内部) 1:冷接点補償を行わない (外部)	0	2
. OY	小数点位置	0:小数点なし	0	0
		1:小数点以下1桁		
		2:小数点以下2桁		
		3:小数点以下3桁 (熱電対/測温抵抗体の小数点付き		
		レンジの場合、0~1)		
05	PVレンジ下限	PVレンジ種類が熱電対、測温抵抗体の 場合、レンジの下限を表示するが、	0	0
		場合、レングの下版を扱がするが、   設定不可		
	PVレンジ種類が直流電圧、直流電流の			
. 06	PVレンジ上限	場合、-1999~十9999U	1000	
. 00	PVレンジ上版	PVレンジ種類が熱電対、測温抵抗体の 場合、レンジの上限を表示するが、	1000	0
		設定不可		
		PVレンジ種類が直流電圧、直流電流の		
. 07	SPリミット下限	場合、-1999~十9999U PVレンジ下限~PVレンジ上限	0	1
08	SPリミット上限		1000	1
.09	開平演算ドロップアウト	0.0~100.0%	0.0	2
T 10	RSPレンジ種類	(0.0で開平演算なし) 0:4~20mA	0	0
. 10	1101 レンノ催規	1:0~20mA	"	"
		2:0~5V		
		3:1~5V		
11	RSPレンジ下限	4:0~10V -1999~+9999U	0	0
: 12	RSPレンジ上限		1000	0
. 14	制御動作(正逆)	0:加熱制御 (逆動作)	0	0
. 15	PV異常時操作量選択	1:冷却制御 (正動作) 0:制御演算を継続する	0	2
		1:PV異常時操作量を出力する		_
16	PV異常時操作量	-10.0~+110.0%	0.0	2
: 11	READY時操作量(加熱冷却 制御の場合は加熱側)	-10.0~+110.0%	0.0	1
. 18	READY時操作量(冷却側)	-10.0~+110.0%	0.0	1
19	MANUAL変更時動作	0:バンプレス	0	1
. 50	プリセットMANUAL値	1:プリセット -10.0~十110.0%	0.0、または	1
	) ) C) I WINTONCIE	(電源ON時に、MANUALモードだった	50.0	<u> </u>
		ときも使用する)		
: 21	PID演算初期化機能選択	0:自動   1:初期化しない	0	2
		2:初期化する (現在値と異なるSP値を		
		入力したとき)		
. 55	PID演算初期操作量	-10.0~+110.0%	0.0、または 50.0	2
. 63	制御パラメータ小数点	0:小数点なし	0	2
		1:小数点以下1桁		
. 24	ゾーンPID動作選択	(積分時間、微分時間の小数点) 0:使用しない	0	2
. 67	ノーンPID動IF選択	0. 使用しない   1:SPによる切り替え	"	-
		2:PVによる切り替え		
. 26	加熱冷却制御選択	0:使用しない	0	0
. 27	加熱冷却切り替え	1:使用する 0:通常	0	1
		1:省エネ		
. 28 . 29	加熱冷却制御不感帯 加熱冷却制御切り替え点	-100.0~+100.0% -10.0~+110.0%	0.0	0
. e9 : 30	ル熱冷却制御切り替え点 LSP使用組数	1~8	50.0	0
31	SPランプ種類	0:標準	0	2
		1:マルチランプ		
		2:ステップ運転 電源再投入時 ステップ停止 (READY)		
		3:ステップ運転 電源再投入時復帰		
32	SPランプ単位	0:0.1U/s	1	2
		1:0.1U/min 2:0.1U/h		
. 33	ステップ運転時間単位	0:0.1s	0	2
		1:1s (コンソールはmin. sで表示)		
5 34	ステップ運転PVスタート	2:1min (コンソールはh. minで表示) 0:使用しない	0	2
	ステック理私FVAメート	0.使用しない   1:使用する		
35	ステップ運転ループ	0:停止 (ループしない)	0	2
		1:ループする		
36	CT1動作	2:最終ステップ継続 (ループしない) 0:ヒータ断線検出	0	0

表示	項目	内 容	初期値	表示レベル
. 37	CT1監視出力	0:制御出力1	0	0
		1:制御出力2		
		2:イベント出力1 3:イベント出力2		
		4:イベント出力3		
. 38 . 39	CT1測定待ち時間 CT2動作	30~300ms 0:ヒータ断線検出	30	0
		1:電流値測定	Ů	
140	CT2監視出力	0:制御出力1	0	0
		1:制御出力2 2:イベント出力1		
		3:イベント出力2		
[4]	CT2測定待ち時間	4:イベント出力3 30~300ms	30	0
142	制御出力1レンジ	電流出力の場合	1	0
		1:4~20mA 2:0~20mA		
		2.0~20IIA		
		連続電圧出力の場合		
		1:1~5V 2:0~5V		
		3:0~10V		
143	制御出力1種類	0:MV 1:加熱MV(加熱冷却制御用)	0	0
		2:冷却MV(加熱冷却制御用)		
		3:PV		
		4:レシオ・バイアス・フィルタ前PV     5:SP		
		6:偏差(PV-SP)		
		7:CT1電流値 8:CT2電流値		
		9:MFB(推定MFBを含む)		
		10:SP+MV		
. 44	制御出力1スケーリング下限	11:PV+MV   -1999~+9999(小数点位置と単位	0.0	0
: 45	制御出力1スケーリング上限	は、制御出力1の種類によって変わる)	100.0	0
148	制御出力1MVスケーリング幅	0~9999 (制御出力1種類が10、11のとき有効)	200	0
. 47	制御出力2レンジ	(制御出力1種類が10、11のとき有効) 制御出力1と同じ	1	0
[ 48 [ 49	制御出力2種類		3	0
. 99 . 50	制御出力2スケーリング下限制御出力2スケーリング上限	-1999〜十9999(小数点位置と単位   は、制御出力2の種類によって変わる)	1000	0
51	制御出力2MVスケーリング幅	0~9999	200	0
. 58	ば助山力1.2.25	(制御出力2種類が10、11のとき有効)	-	_
. 5c . 53	補助出力レンジ 補助出力種類	制御出力1と同じ	3	0
. 54	補助出力スケーリング下限	-1999~+9999 (小数点位置と単位	0	0
7 55 7 56	補助出力スケーリング上限 補助出力MVスケーリング幅	は、補助出力種類によって変わる) 0~9999	1000 200	0
	IHDJ口ブWVハブ ブンブ国	(補助出力種類が10、11のとき有効)	200	
57	位置比例制御方法選択	0:MFB制御十推定位置制御	0	0
		1:MFB制御   2:推定位置制御(MFB使わない)		
		3:推定位置制御(MFB使わない)		
. 58	位置比例制御デッドゾーン	十電源投入時位置合わせ 0.5~25.0%	10.0	0
59	位置比例制御長寿命	0:制御性重視	1	0
. 60	<b>公里以</b> 加州如明教明4	1:ポテンショメータ寿命重視 0:停止		
. 00	位置比例制御調整開始	0 : 停止   1:開始	0	0
51	位置比例全閉調整值	0~9999	1000	0
[ 62 [ 63	位置比例全開調整值 位置比例全開時間	0~9999 5.0~240.0s	3000 30.0	0
. 64	通信種類	0:CPL	0	0
		1:MODBUS ASCII形式 2:MODBUS RTU形式		
7 65	機器アドレス	0~127	0	0
	/- \/ \ d=	(0のとき通信しない)		
. 66	伝送速度	0:4800bps 1:9600bps	2	0
		2:19200bps		
. 67	データ形式 (データ長)	3:38400bps 0:7ビット	1	0
	, /ル丸(/ ***   *******************************	1:8ビット	L '	_
. 68	データ形式 (パリティ)	0:偶数パリティ	0	0
		1:奇数パリティ 2:パリティなし		
69	データ形式 (ストップビット)	0:1ビット	0	0
5 70	通信最小応答時間	1:2ビット 1~250ms	3	2
. <i>10</i> [7]	キー操作種類	0:標準タイプ	0	2
72	modeキー機能	1:特殊タイプ 0:無効	1	0
. 10	mode十一機能	0:無効 1:AUTO/MANUAL切り替え	'	"
		2:RUN/READY切り替え		
		3:AT停止/起動 4:LSP組切り替え		
		5:全DOラッチ解除		
		6:LSP/RSP切り替え		
		7:通信DI1切り替え 8:無効		
. 73	モード表示設定	モードバンクの設定表示有無を下記の	255	1
		重み付けの和で決める ビット0:AUTO/MANUAL表示		
		なし:0、あり:+1		
		ビット1:RUN/READY表示		
		なし:0、あり:+2 ビット2:LSP/RSP表示		
		なし:0、あり:+4		
		ビット3:AT停止/起動表示 なし:0、あり:+8		
		ばし:0、あり:+8 ビット4:DOラッチ解除表示		
		なし:0、あり:+16		
		ビット5:通信DI1 ON/OFF表示 なし:0、あり:+32		
		その他無効な設定 0、+64、+128		
	•	•		

CP-UM-5289JE

J3 (裏面に続きます)

表示	項目	内 容	初期値	表示レベル
ניזא	PV/SP值表示設定	基本表示の表示有無を下記の重み付け の和で決める	15	1
		ビット0:PV表示 なし:0、あり:+1		
		ビット1:SP表示 なし:0、あり:+2		
		ビット2:LSP組番号表示 なし:0、あり:+4		
C 75	操作量表示設定	その他無効な設定 0、+8 基本表示の表示有無を下記の重み付け	15	1
		の和で決める ビット0:MV表示		
		なし:0、あり:+1 ビット1:加熱MV/冷却MV表示		
		なし:0、あり:+2 ビット2:MFB表示		
		なし:0、あり:+4 ビット3:AT進捗表示		
C 76	イベント設定値表示設定	なし:0、あり:+8 0:運転表示に内部イベント設定値を	0	1
		表示しない 1:運転表示に内部イベント1設定値を		
		表示する 2:運転表示に内部イベント1~2設定値		
		を表示する 3:運転表示に内部イベント1~3設定値 を表示する		
c 11	イベント残り時間表示設定	0:運転表示に内部イベントのON/OFF	0	1
		ディレイ残り時間を表示しない 1:運転表示に内部イベント1のON/OFF ディレイ残り時間を表示する		
		2:運転表示に内部イベント1~2のON/ OFFディレイ残り時間を表示する		
		3:運転表示に内部イベント1~3のON/ OFFディレイ残り時間を表示する		
C 78	CT入力電流值表示設定	0:運転表示にCTの電流値を表示しない	0	1
		1:運転表示にCT1電流値を表示する   2:運転表示にCT1~2電流値を表示		
C 79	表示レベル	する 0:簡単設定	1	0
		1:標準設定 2:多機能設定		
C 80	LEDモニタ	0:使用しない 1:RS-485通信送信時点滅	0	2
		2:RS-485通信受信時点滅 3:全DI状態のOR (論理和)		
C81	MS表示灯点灯条件	4: READY時点滅 0: 常時開 (常時OFF=0)	39	2
	(第1優先)	1:常時閉 (常時ON=1) 2~9:内部イベント1~8		
		10~13:未定義   14:MV1 (ON/OFF、時間比例1、		
		加熱側、OPEN側出力) 15:MV2 (時間比例2、冷却側、		
		CLOSE側出力) 16~17:未定義		
		18~21:DI1~DI4 22~25:未定義		
		26~30: 内部接点1~5 31~33: 未定義		
		34~37:通信DI1~DI4 38:MANUAL		
		39 : READY 40 : RSP		
		41:AT 42:ランプ中		
		43:未定義 44:アラーム		
		45:PVアラーム 46:未定義		
		47:modeキー押し状態 48:イベント出力1端子の状態		
C 82	MS表示灯点灯状態 (第1優先)	49:制御出力1端子の状態   0:点灯   1:遅い点滅	1	2
	(ND 19676)	1・遅い点滅   2:2回点滅   3:速い点滅		
		3.迷い点版 4:左→右 5:右→左		
		6:左右往復 7:偏差OK		
		8:偏差グラフ 9:MVグラフ		
		10:加熱側MVグラフ 11:冷却側MVグラフ		
		12:MFBグラフ 13:DIモニタ		
		14:内部接点モニタ 15:内部イベントモニタ		
C 83	MS表示灯点灯条件 (第2優先)	MS表示灯点灯条件 (第1優先) と同じ	44	2
C 84	MS表示灯点灯状態 (第2優先)	MS表示灯点灯状態 (第1優先) と同じ	6	2
C 85	MS表示灯点灯条件 (第3優先) MS表示灯点灯状態	MS表示灯点灯条件 (第1優先) と同じ MS表示灯点灯状態 (第1優先) と同じ	1 9	2
C 87	MS表示灯点灯状態 (第3優先) MS表示灯偏差範囲	MS表示灯点灯状態 (第1後光) と同じ 0~9999U	5	2
C 88	特殊機能	0~15 (電源ON時に0になる)	0	2
C 89	ツェナーバリア調整	調整による書き替えは可能 手動による数値入力は不可	0.00	2
C 90	CT1ターン数	0:800ターン 1~40:設定値の100倍をターン数とする	8	2
(91	CT1電力線貫通回数	0:1回 1~6:回数	1	2

表示	項目	内 容	初期值	表 示 レベル
C 92	CT2ターン数	0:800ターン 1~40:設定値の100倍をターン数とする	8	2
( 93	CT2電力線貫通回数	0:1回 1~6:回数	1	2

### ■ イベントコンフバンク バンク選択:どいごと

表示	項目	内 容	初期値	表 示レベル
E1.C1 ~ E8.C1	内部イベント1〜8 コンフ1 動作種類	<ul> <li>0:イベントなし</li> <li>1: PV上限</li> <li>2: PV下限</li> <li>3: PV上下限</li> <li>4: 偏差上限</li> <li>5: 偏差上下限</li> <li>6: 偏差上下限</li> <li>6: 偏差上限(最終SP基準)</li> <li>9: 偏差上下限(最終SP基準)</li> <li>10: SP上限</li> <li>11: SP下限</li> <li>12: SP上下限</li> <li>13: MV上限</li> <li>14: MV下限</li> <li>15: MV上下限</li> <li>16: CT1セータ断線/過電流</li> <li>17: CT1セータ短絡</li> <li>18: CT2ヒータ短絡</li> <li>18: CT2ヒータ短絡</li> <li>19: CT2ヒーシが診断</li> <li>20: ループ診断</li> <li>21: ループ診断</li> <li>22: ループ診断</li> <li>23: アラーム(状態)</li> <li>24: READY(状態)</li> <li>25: MANUAL(状態)</li> <li>26: RSP(状態)</li> <li>27: AT起動中(状態)</li> <li>29: 制御正動作(状態)</li> <li>30: 無効</li> <li>31: モータ開度推定中(状態)</li> <li>32: タイマ(状態)</li> <li>33: MFB上下限</li> </ul>	0	0
E 1. C2 ∼ E8. C2	内部イベント1~8 コンフ2 1桁目:正逆	右側から1、2、3、4桁とする   0:正	0000	0
	2桁目:待機	1:逆   0:なし   1:待機   2:待機+SP変更時待機	0	-
	3桁目:READY時動作 4桁目:未定義	0:継続 1 強制OFF	0	
E1.C3 ~	内部イベント1~8 コンフ3	右側から1、2、3、4桁とする	0000	2
E8. C3	1桁目:アラームOR	0:なし 1:アラーム正十OR動作 2:アラーム正十AND動作 3:アラーム逆十OR動作 4:アラーム逆+AND動作	0	
	2桁目:特殊OFF	0:通常どおり 1:イベント設定値 (主) =0の場合、 イベントOFF	0	
	3桁目:ディレイ時間単位	0:0.1s 1:1s 2:1min	0	
	4桁目:未定義	0	0	

### ■ DI割り付けバンク バンク選択: 🖧

表示	項目	内 容	初期值	表 示レベル
d1.1 ~ d15.1	内部接点1~5 動作種類	0:機能なし 1:LSP組選択 (0/+1) 2:LSP組選択 (0/+2) 3:LSP組選択 (0/+4) 4:PID組選択 (0/+4) 4:PID組選択 (0/+4) 7:RUN/READY切り替え 8:AUTO/MANUAL切り替え 9:LSP/RSP切り替え 10:AT停止/起動 11:無効 12:制御動作正逆切り替え (設定とおり/設定の反対) 13:SPランプ許可禁止 14:PV値ホールド (ホールドせず/ホールド) 15:PV最大値ホールド (ホールドせず/ホールド) 16:PV最大値ホールド (ホールドせず/ホールド) 17:タイマ停止/起動 18:全DOラッチ解除 (継続/解除) 19:アドバンス (アドバンスせず/アドバンス) 20:ステップホールド (ホールドせず/ホールド)	0	0
d11.2 ∼ d15.2	内部接点1~5 入力ビット演算	0:使用しない(デフォルトの入力) 1:演算1 ((A and B) or (C and D)) 2:演算2 ((A or B) and (C or D)) 3:演算3 (A or B or C or D) 4:演算4 (A and B and C and D)	0	2

表示	項目	内容	初期値	表示
			1,374,71	レベル
d11.3 ~	内部接点1~5	0:常に開 (OFF、0)	2~5	2
d15. 3	入力割り付けA	1:常に閉 (ON、1)	または	
		2: DI1 3: DI2	0	
		4 : DI3		
		5 : DI4		
		6~9:未定義		
		10:内部イベント1		
d11,4 ~	内部接点1~5	11:内部イベント2	0	2
d15, 4	入力割り付けB	12:内部イベント3	•	-
		13: 内部イベント4		
		14:内部イベント5		
		15:内部イベント6		
		16:内部イベント7		
		17:内部イベント8		
		18:通信DI1		
dil.5 ~	内部接点1~5	19:通信DI2	0	2
d15. 5	入力割り付けC	20:通信DI3		
		21:通信DI4 22:MANUALモード		
		23: READYE - F		
		24 : BSP ₹ — ド		
		25:AT起動中		
		26:SPランプ中		
di 1. 6 ~	内部接点1~5	27:未定義	0	2
d15. 6	入力割り付けD	28:アラームあり		
		29:PVアラームあり		
		30:未定義		
		31: modeキー押し状態		
		32:イベント出力1端子状態		
d11,7 ~		33:制御出力1端子状態	0000	
di5.7 ~	内部接点1~5 反転A~D 1桁目:反転A	右側から1、2、3、4桁とする 0:反転しない	0000	2
0/3. 1	(入力割り付けAの反転)	1:反転する	"	
	2桁目:反転B	/	0	1 1
	(入力割り付けBの反転)		•	
	3桁目:反転C		0	1
	(入力割り付けCの反転)			
	4桁目:反転D		0	
	(入力割り付けDの反転)			
d(1.8 ~	内部接点1~5 反転	0:反転しない	0	2
d15. 8 d11. 9 ∼	内部接点1~5	1:反転する 0:すべての内部イベント	0	2
011.9 ~ 015.9	内部接点1~5   内部イベント番号指定	0 . すべくの内部1 ベント   1~8:内部イベント番号	"	2
ר וכוט	「対印「ハント借与相圧	10・トメヨロン1 ハンド借方	L	

### ■ DO割り付けバンク バンク選択:♂₀

項目

οΕ1.1 ~ οΕ2.1 Ευ1.1 ~ Ευ3.1	制御出力1~2、イベント 出力1~3 動作種類	0:デフォルトの出力 1:MV1(ON/OFF制御出力、時間比例 出力、加熱冷却制御の加熱側時間 比例出力)	0	2
		2: MV2 (加熱冷却制御の冷却側時間 比例出力) 3: 演算1 ((A and B) or (C and D)) 4: 演算2 ((A or B) and (C or D))		
		5:演算 3 (A or B or C or D)		
ot1.2 ~	   制御出力1~2、イベント	6:演算 4 (A and B and C and D) 0:常に開 (OFF、 0 )	14~15	2
oc 1. c ~ ot2. 2	制御田ガ1~2、1 ベント     出力1~3	0 . 常に開 (OFF、 0 )   1:常に閉 (ON、1)	14~15 または	2
ec. c Eu 1, 2 ~	出力割り付けA	1 - 吊に闭 (ON、1)   2 : 内部イベント1	2~4	
Eu3. 2	山刀割りNVA	3:内部イベント2	2.4	
203. 2		4:内部イベント3		
		5:内部イベント4		
		6:内部イベント5		
		7:内部イベント6		
		8:内部イベント7		
		9:内部イベント8		
ot 1.3 ~	制御出力1~2、イベント	10~13:未定義	0	2
ot2. 3	出力1~3	14: MV1		
Eu 1. 3 ~	出力割り付けB	15: MV2		
Eu3. 3		16~17:未定義		
		18: DI1		
		19: DI2		
		20 : DI3		
		21 : DI4		
		22~25:未定義 26:内部接点 1		
ot 1.4 ~	制御出力1~2、イベント	27:内部接点2	0	2
o£2. Y	出力1~3	28: 内部接点 3		
Eu 1. 4 ~	出力割り付けC	29:内部接点 4		
Eu3. 4		30: 内部接点 5		
		31~33:未定義		
		34:通信DI1		
		35:通信DI2		
		36:通信DI3		
		37:通信DI4		
		38:MANUALモード		
ot 1.5 ~	制御出力1~2、イベント	39:READYモード	0	2
o£2. 5	出力1~3	40 : RSPモード		
Eu 1.5 ~	出力割り付けD	41:AT起動中		
Eu3. 5		42:SPランプ中		
		43:未定義		
		44:アラームあり		
		45:PVアラームあり 46:未定義		
		40・小儿我	1	
		47 · modo 七 — 畑   壮能		
		47: modeキー押し状態 48: イベント出力 1 端子状態		

内容

初期値 表 示

表示	項目	内 容	初期値	表 示 レベル
o£1.6 ~ o£2.6	制御出力1~2、イベント 出力1~3 反転A~D	右側から1、2、3、4桁とする	0000	2
Eu 1. 6 ~	1桁目:反転A	0:反転しない	0	
Eu3. 6	2桁目:反転B	1:反転する	0	
	3桁目:反転C		0	
	4桁目:反転D		0	
ot1.7 ~	制御出力1~2、イベント	0:反転しない	0	2
ot2.7	出力1~3	1:反転する		
Eu 1.7 ~	反転			
Eu 3. 7				
ot 1.8 ~	制御出力1~2、イベント	0:なし	0	2
ot2. 8	出力1~3	1:あり (ONでラッチ)		
Eu 1. 8 ~	ラッチ	2:あり (OFFでラッチ、電源投入		
Eu3.8		初期化時は除く)		

#### ■ ユーザーファンクションバンク バンク選択:UF

表示	項目	内 容	初期値	表 示 レベル
UF-1	ユーザーファンクション定義1	各設定の第1表示部の表示で、設定 例外は下記のとおり		1
UF-2	ユーザーファンクション定義2	: 未登録		1
UF-3	ユーザーファンクション定義3	P :使用中PID組の比例帯 :使用中PID組の積分時間		1
UF-4	ユーザーファンクション定義4	<ul><li>d :使用中PID組の微分時間</li><li>r. E :使用中PID組のマニュアルリセット</li></ul>		1
UF-5	ユーザーファンクション定義5	ok :使用中PID組の操作量下限 oK :使用中PID組の操作量上限		1
UF-6	ユーザーファンクション定義6	PC : 使用中PID組の冷却側比例帯 C : 使用中PID組の冷却側積分時間		1
UF-7	ユーザーファンクション定義7	d€:使用中PID組の冷却側微分時間		1
UF-8	ユーザーファンクション定義8	ok{ : 使用中PID組の冷却側操作量下限 ok{ : 使用中PID組の冷却側操作量上限		1

### ■ ロックバンク バンク選択:LoC

表示	項目	内 容	初期値	表 示 レベル
LoC	キーロック	<ul> <li>0:すべて設定が可能</li> <li>1:モード、イベント、運転表示、SP、UF、ロック、マニュアルMVの設定が可能</li> <li>2:運転表示、SP、UF、ロック、マニュアルMVの設定が可能</li> <li>3:UF、ロック、マニュアルMVの設定が可能が可能</li> </ul>	0	0
C. LoC	通信ロック	0:RS-485通信read/write可能 1:RS-485通信read/write不可	0	2
L. LoC	ローダロック	0:ローダ通信read/write可能 1:ローダ通信read/write不可	0	2
PR55	パスワード表示	0~15 5:パスワード1A~2B表示	0	0
PS 18	パスワード1A	0000~FFFF (16進数)	0000	0
PSER	パスワード2A	0000~FFFF (16進数)	0000	0
PS 16	パスワード1B	0000~FFFF (16進数)	0000	0
P52b	パスワード2B	0000~FFFF (16進数)	0000	0

# ■ 計器情報バンク バンク選択:

表示	項目	内 容	初期値	表示レベル
1801	ROM ID	2固定	_	2
1808	ROM バージョン1	XX. XX (小数点以下2桁)	_	2
1603	ROM バージョン2	XX. XX (小数点以下2桁)	_	2
1804	SLP対応バージョン		_	2
1805	EST対応バージョン		_	2
1606	デートコード 年	西暦-2000 例:2003年は「3」	_	2
1807	デートコード 月日	月十(日÷100) 例:12月1日は「12.01」	_	2
1808	製造番号		_	2

〔ご注意〕この資料の記載内容は、お断りなく変更する場合もありますのでご了承ください。

アドバンスオートメーションカンパニー

本 社 〒100-6419 東京都千代田区丸の内2-7-3 東京ビル

北海道支店 電(011)781-5396 中部支社 電(052)238-3037 東北支店 電(022)292-2004 関西支社 電(06)6881-3383~4 北関東支店 電(048)653-8733 中国支店 電(082)554-0750

東京支社 ☎(03)6810-1200 九州支社 ☎(093)952-1210

〈COMPO CLUBアドレス〉 http://www.compoclub.com 〈山武ホームページアドレス〉 http://jp.azbil.com

この資料は再生紙を使用しています。 (14)

2003年 9月 初版発行(A) 2008年 3月 改訂15版(B)

### SDC35/36 **Single Loop Controller User's Manual** for Installation

Thank you for purchasing the SDC35/36.

Before operating the product described in this user's manual, please take note of the following points regarding safety.

Be sure to keep this manual nearby for handy reference.

#### = RESTRICTIONS ON USE =

This product has been designed, developed and manufactured for general-purpose application in machinery and equipment. Accordingly, when used in applications outlined below, special care should be taken to implement a fail-safe and/or redundant design concept as well as a periodic maintenance program.

- Safety devices for plant worker protection
- Start/stop control devices for transportation and material handling machines
- · Aeronautical/aerospace machines
- Control devices for nuclear reactors

Never use this product in applications where human safety may be put at risk.

### **NOTICE**

Be sure that the user receives this manual before the product is used. Copying or duplicating the manual in part or in whole is forbidden.

The information and specifications in the manual are subject to change without notice.

Considerable effort has been made to ensure that this manual is free from inaccuracies and omissions. If you should find an error or omission, please contact Yamatake Corporation

In no event is Yamatake Corporation liable to anyone for any indirect, special or consequential damages as a result of using this product.

©2003 Yamatake Corporation ALL RIGHTS RESERVED

This manual explains the handling precautions, mounting, wiring, PV range type, list of parameters and main specifications only. See the separate Installation & Configurations manual listed below for the detail handling procedures and the setting methods, etc. These manuals also contain information on using various functions. Please read if necessary.

SDC35/36 Single Loop Controller User's Manual for

Basic Operations CP-SP-1150E

SLP-C35 Smart Loader Package for SDC15/25/26/35/36 Single Loop Controller User's Manual CP-UM-5290E

SDC35/36 Quick Reference Guide CP-SP-1203E

#### ■ Unpacking

Check the following items when removing the SDC35/36 from its package:

Part No Name Remarks Mounting Bracket 81409654-001 User's Manual CP-UM-5289JE This Manual

### **SAFETY PRECAUTIONS**

Warnings are indicated when mishandling WARNING this product might result in death or serious injury to the user.

Cautions are indicated when mishandling CAUTION this product might result in minor injury to the user, or only physical damage to this

### **∴** WARNING

- Note that incorrect wiring of the SDC35/36 can damage the SDC35/36 and lead to other hazards. Check that the SDC35/36 has been correctly wired before turning the power ON.
- Before wiring, or removing/mounting the SDC35/36, be sure to turn the power OFF.
  - Failure to do so might cause electric shock or faulty operation.
- Do not touch electrically charged parts such as the power terminals. Doing so might cause electric shock.
- Do not disassemble the SDC35/36. Doing so might cause electric shock or faulty operation.

### **♠** CAUTION

- Use the SDC35/36 within the operating ranges recommended in the specifications (temperature, humidity, voltage, vibration, shock, mounting direction, atmosphere, etc.). Failure to do so might cause fire or faulty operation.
- Do not block ventilation holes.
- Doing so might cause fire or faulty operation.
- Wire the SDC35/36 properly according to predetermined standards. Also wire the SDC35/36 using specified power leads according to recognized installation methods.
- Failure to do so might cause electric shock, fire or faulty operation Do not allow lead clippings, chips or water to enter the controller case.
- Doing so might cause fire or faulty operation. Firmly tighten the terminal screws at the torque listed in the specifications.
- Insufficient tightening of terminal screws might cause electric shock or fire.
- Do not use unused terminals on the SDC35/36 as relay terminals. Doing so might cause electric shock, fire or faulty operation.
- We recommend attaching the terminal cover (sold separately) after wiring the SDC35/36. Failure to do so might cause electric shock.
- Use the relays within the recommended service life. Failure to do so might cause fire or faulty operation.
- To avoid the risk of fire or device failure, use Yamatake Corporation's SurgeNon if there is a chance of power surges caused by lightning.
- Do not operate the keys with a mechanical pencil or other sharptipped object. Doing so might cause faulty operation.

### Mounting

#### ■ Location

Install the controller in a location that meets the following criteria:


- · Common mode voltages of I/O except power supply and relay contact output: The voltage to ground is 33Vr.m.s max., 46.7V peak max., and 70Vdc max.
- Neither high nor low temperature/humidity.
- No corrosive gases such as sulfide gas.
- · Little dust or soot
- Protected from direct sunlight, wind or rain.
- Little mechanical vibration and shock.
- Not close to a high voltage line, welding machine or other source of
- At least 15 meters away from a high voltage ignition device for a boiler.
- No strong magnetic field.
- No flammable liquid or gas.

### **■** Mounting Procedure


- The mounting must be horizontal within 10 degrees tilted in back side lowering or within 10 degrees tilted in back side rising
- The mounting panel should be used with a thickness of less than 9 mm of firm board.

#### **■** External Dimensions

· C35 (unit: mm)



· C36




### ! Handling Precautions


To fasten this controller onto the panel, tighten the mounting bracket screws, and then turn one more full turn when there is no play between the bracket and panel. Excessively tightening the screws may deform the controller case.

#### ■ Panel Cutout Dimensions

· C35 (unit: mm)



· C36



### ! Handling Precautions

When three or more units are gang-mounted horizontally, the maximum allowable ambient temperature is 40°C.

### Wiring

Be sure to provide a switch within operator reach for shutting OFF the main power supply to the controller in the main supply wiring.

Also, in case of AC power supply models, the main supply wiring also requires a time-lagged type (T) fuse (rated current: 0.5A, rated voltage: 250 V). (IEC127) The following table shows the meaning of the symbols in the terminal wiring label on the controller side:


Symbols	Meaning
?	AC power supply
===	DC power supply
A	Caution, electric shock hazard
<u> </u>	Caution

### ! Handling Precautions

- Before wiring the SDC35/36, verify the controller's model No. and terminal Nos. written on the label on the side of the body. Inspect all wiring once wiring work for the SCD35/36 has been completed.
- Use M3 crimp-type terminal lugs for wiring to terminal.
- Leave at least 50cm between I/O signal wires and power wires. Do not put them in the same electrical conduit or duct.
- Be careful not to allow any crimp-type terminal lugs to touch adiacent terminals. · Prepare a heater current conductor to send a heater current
- through the current transformer. Do not use a heater current that exceeds the specified permissible current as this may damage the controller
- The current transformer input cannot be used for phase control.


- · There is no isolation provided between control output 1 and control output 2.
- Install an isolator as required.
- · Do not connect a terminating resistor to either end of the RS-485 communications line. Doing so may interfere with communication.
- · When the power supply voltage of the motor which is connected to the motor drive relay output is 100/200Vac, use an auxiliary relay externally.
- · Do not wire in the same duct for the motor drive terminals (13),(14),(15) and the MFB input terminals (7),(8), (9) and also do not use 6-core cable. Failure to follow the instruction might cause controller malfunction due to noise during motor startup
- · Regarding a device or equipment which is connected to this controller, use a model to which the basic insulation meeting with the power supply voltage and the maximum operating voltage of the I/O units is provided
- The controller requires maximum 5 seconds to start up once the power is turned ON.
- The controller can be used once it has started up. However, it is recommended to allow a warm-up time of at least 30 minutes to attain the specified accuracy.

#### Connection of C35/36



#### I/O isolation


Items surrounded by solid lines are insulated from other signals.



Availability of input or output is based on a model number.

Note 1 In case of independent contact, the part between the event output 1 and the event output 2 is isolated

#### Part names and functions



(1) Upper display: (2) Lower display:

Displays PV values (present temperature etc.) or setting items. Displays SP values (set temperature, etc.) and other parameter

When the lower display shows the SP value, the "sp" lamp lights up. When the display shows the manipulated variable (MV), the "out" lamp lights up.

Lights when MANUAL (manual mode) (3) Mode indicator man: Lights when RSP mode (remote setup input)

> ev1 to ev3: Lights when event relays are ON. ot1 to ot2: Lights when the control output is ON.

(4) Multi-status indicator:

In the combination of the lighting condition and the lighting status as a group, the priority 3 groups can be set.

(5) [mode] key: The operation which has been set beforehand can be done by pushing the key for 1s or more. (6) [display] key:

Used to change the display contents in the operation display mode. Display is returned from bank setup display to operation display.

Used for incrementing numeric values and performing  $(7) < , \lor, \land \text{key}$ : arithmetic shift operations.

(8) [para] key: Switchs the display.

(9) [enter] key: Used to set the setup values at the start of change and during the change.

(10) Loader connector: Connects to a personal computer by using a dedicated cable supplied with the Smart Loader Package.

### PV range table

CO1 Set value	Sensor type	Range		C01 Set value	Sensor type	Rai	nge
1	K	-200 to +1200°C	-300 to +2200°F	41	Pt100	-200.0 to +500.0°C	-300 to +900°F
2	K	0 to 1200°C	0 to 2200°F	42	JPt100	-200.0 to +500.0°C	-300 to +900°F
3	K	0.0 to 800.0°C	0 to 1500°F	43	Pt100	-200.0 to +200.0°C	-300 to +400°F
4	K	0.0 to 600.0°C	0 to 1100°F	44	JPt100	-200.0 to +200.0°C	-300 to +400°F
5	K	0.0 to 400.0°C	0 to 700°F	45	Pt100	-100.0 to +300.0°C	-150 to +500°F
6	K	-200.0 to +400.0°C	-300 to +700°F	46	JPt100	-100.0 to +300.0°C	-150 to +500°F
7	K	-200.0 to +200.0°C	-300 to +400°F	47	Pt100	-100.0 to +200.0°C	-150 to +400°F
8	J	0 to 1200°C	0 to 2200°F	48	JPt100	-100.0 to +200.0°C	-150 to +400°F
9	J	0.0 to 800.0°C	0 to 1500°F	49	Pt100	-100.0 to +150.0°C	-150 to +300°F
10	J	0.0 to 600.0°C	0 to 1100°F	50	JPt100	-100.0 to +150.0°C	-150 to +300°F
11	J	-200.0 to +400.0°C	-300 to +700°F	51	Pt100	-50.0 to +200.0°C	-50 to +400°F
12	E	0.0 to 800.0°C	0 to 1500°F	52	JPt100	-50.0 to +200.0°C	-50 to +400°F
13	Е	0.0 to 600.0°C	0 to 1100°F	53	Pt100	-50.0 to +100.0°C	-50 to +200°F
14	T	-200.0 to +400.0°C	-300 to +700°F	54	JPt100	-50.0 to +100.0°C	-50 to +200°F
15	R	0 to 1600°C	0 to 3000°F	55	Pt100	-60.0 to +40.0°C	-60 to +100°F
16	S	0 to 1600°C	0 to 3000°F	56	JPt100	-60.0 to +40.0°C	-60 to +100°F
17	В	0 to 1800°C	0 to 3300°F	57	Pt100	-40.0 to +60.0°C	-40 to +140°F
18	N	0 to 1300°C	0 to 2300°F	58	JPt100	-40.0 to +60.0°C	-40 to +140°F
19	PLII	0 to 1300°C	0 to 2300°F	59	Pt100	-10.00 to +60.00°C	-10 to +140°F
20	Wre5-26	0 to 1400°C	0 to 2400°F	60	JPt100	-10.00 to +60.00°C	-10 to +140°F
21	Wre5-26	0 to 2300°C	0 to 4200°F	61	Pt100	0.0 to 100.0°C	0 to 200°F
22	Ni-NiMo	0 to 1300°C	0 to 2300°F	62	JPt100	0.0 to 100.0°C	0 to 200°F
23	PR40-20	0 to 1900°C	0 to 3400°F	63	Pt100	0.0 to 200.0°C	0 to 400°F
24	DIN U	-200.0 to +400.0°C	-300 to +700°F	64	JPt100	0.0 to 200.0°C	0 to 400°F
25	DIN L	-100.0 to +800.0°C	-150 to +1500°F	65	Pt100	0.0 to 300.0°C	0 to 500°F
26	Gold iron	0.0K to 360.0K	0 to 360K	66	JPt100	0.0 to 300.0°C	0 to 500°F
	chromel			67	Pt100	0.0 to 500.0°C	0 to 900°F
_				68	JPt100	0.0 to 500.0°C	0 to 900°F

### ! Handling Precautions

The accuracy is ±0.1%FS±1 digit, and ±0.2%FS±1 digit for a negative area of the thermocouple The accuracy varies according to the

The accuracy of the No.17 (sensor type

B) is ±4.0%FS for a range of 260°C or less, ±0.4%FS for 260 to 800°C and ±0.2%FS for 800 to 1800°C. The PV values under 20°C are not shown. The accuracy of the No.15 (sensor type 90 4 to 20mA

R) or No.16 (sensor type S) is ±0.2%FS for a range of 100°C or less, and ±0.15%FS for 100 to 1600°C.

The accuracy of the No.23 (sensor type PR40-20) is ±2.5%FS for 0 to of 300°C, and  $\pm 1.5\%$ FS for 300 to 800°C,  $\pm 0.5\%$ FS for 800 to of 1900°C. The accuracy of the No.26 (sensor type gold iron chromel) is  $\pm 1.5$ K.

Input type

0 to 1V

0 to 5V

0 to 20mA

88 0 to 10V

82 -10 to +10mV point position can be

0 to 100mV changed variably in a range

of -1999 to +9999.

The scaling and the decim


81 0. to 10mV

The accuracy of the No. 55 to 62 and 81 are ±0.15%FS for each range The accuracy of the No.19 (sensor type PLII) in the range of 0 to 32°F does not meet the indication accuracy.

The ranges with a decimal point show figures under decimal point.

### Setting the PV range type

The following shows the flow of key operation:



There are the standard type and special type in the data setup method. Here, the method is explained in the standard type.

#### Setting example of the PV range type

Display the  $\mathcal{L}\mathcal{U}$  on the upper display in the bank setup mode for the setup bank. When the [enter] key is pressed, the numerical value on the lower display will start to flash. Move the digit or increase/decrease the numeric value by pressing the [<]  $[\lor]$   $[\land]$  keys. When the [enter] key is pressed at the desired numeric value, the flashing will stop and the data will be set.

#### Setting example of the SP1

Display the 5P - t on the upper display in the bank setup mode of the setup bank. When the [enter] key is pressed, the numerical value on the lower display will start to flash. Move the digit or increase/decrease the numeric value by pressing the [<] [ V ] [ A ]

When the [enter] key is pressed at the desired numeric value, the flashing will stop and

For the details of the handling and setting method, refer to the following manual:

SDC35/36 User's Manual "Installation & Configurations" CP-SP-1150E and SDC35/36 Quick Reference Guide.

### Alarm code table

This table shows the alarm display and measures for the abnormal operation of this controller

Alarm code	Failure name	Cause	Corrective action
RLO I	PV input failure (over range)	Sensor line break, incorrect wiring, incorrect PV range type setting	Checking wiring or reset PV range type
RLO2	PV input failure (under range)	Sensor line break, incorrect wiring, incorrect PV range type setting	
RL03	CJ failure failure	Terminal temperature is faulty (thermocouple).	Checking the ambient temperature.
	PV input failure	Sensor line break, incorrect wiring (RTD)	Checking wiring.
RLOS	RSP input failure (Over range) (Displays in RSP mode)	Sensor line break, incorrect wiring, incorrect RSP range setting	Checking wiring or reset RSP range code.
RLO6	RSP input failure (Under range) (Displays in RSP mode)	Sensor line break, incorrect wiring, incorrect RSP range setting	Checking wiring or reset RSP range code.
RL07	MFB input failure	Motor line break, incorrect wiring	Checking wiring or confirm the MFB input.
RL 10	Motor adjustment failure	Motor line break, incorrect wiring, motor power supply failure.	Checking wiring, confirm the motor power supply, reset.
RUI	CT input failure (over-range) (CT input 1 or 2,or both)	A current exceeding the upper limit of the display range was measured. The number of CT turns or the number of CT power wire loops is incorrectly set, or wiring is incorrect.	Use a CT with the correct number of turns for the display range, reset the number of CT turns, reset the number of CT power wire loops, and/or check the wiring.
RL70	A/D conversion failure	Defective A/D converter	Replace unit.
RL95	Parameter failure	Power turned OFF during fixing data Data corrupted due to noise, etc.	Re-start the system. Reset data or replace unit. (AL95/97: setting
RL96	Adjustment data	Power turned OFF during fixing data Data corrupted due to noise, etc.	data, AL96/98: tuning data)
RL97	Parameter failure (RAM area)	Data corrupted due to noise, etc.	
RL98	Adjustment data failure (RAM area)	Data corrupted due to noise, etc.	
<i>R</i> L99	ROM failure	ROM (memory) error	Re-start the system. Replace unit.

#### Maintenance

When wiping out the SDC35/36, use the soft and dried cloth. Cleaning

Parts replacement Do not replace the parts. Fuse replacement

On AC models, when replacing the fuse for the power, make sure that the replacement fuse complies with applicable standards. Use a time lag fuse (T) compliant with IEC127 and rated at 250V, 0.5A.

### Model selection table

Basic model No.	Mounting	Control output	PV input	Power supply	Option 1	Option 2	Additions 1	Additions 2	Specific	cations	
C35		output	iriput	Supply	<u> </u>	-	<u> </u>		48X96 size model		
C36					_		_		96X96 size model		
000	Т	-		-		_	$\vdash$		Panel mounting typ	10	
	<u> </u>	$\vdash$			_		_		Control output 1	Control output 2	
		R0							Relay contact output NO	Relay contact output NC	
(No	te 3)	R1							Relay contact output	Relay contact output	
									for motor drive OPEN side	for motor drive CLOSE side	
		V0							Voltage pulse output (for SSR drive)	_	
		VC							Voltage pulse output (for SSR drive)	Current output	
		VD							Voltage pulse output (for SSR drive)	Voltage output	
		VV							Voltage pulse output (for SSR drive)	Voltage pulse output (for SSR drive)	
		C0							Current output	_	
		CC							Current output	Current output	
		CD							Current output	Voltage output	
		DO							Voltage output		
		DD							Voltage output	Voltage output	
			U						Universal		
				Α					AC model (100 to 2		
				D					DC model (24Vac/24Vdc)		
					1				Event relay output		
					2				Event relay output a Auxiliary output (cu		
					3				Event relay output : Auxiliary output (vo		
		1)	Note 3	)	4				Event output: 2 poil contact)	nts (independent	
		1)	Note 3	)	5				Event output: 2 poil contact)	nts (independent	
		/1	Note 3	`	6				Auxiliary output (cu		
		(1	VOIG 5	,	0				contact) Auxiliary output (vo	` .	
						0				nago oatpat)	
			(N	lote 1,2	2)	1			Current transformer input: 2 points Digital input: 4 points		
			(N	lote 1,2	2)	2			Current transforme		
									Digital input: 4 point communication	s, RS-485	
			(N	lote 1,2	2)	3			Current transforme Digital input: 2 poin		
			(N	lote 1,2	2)	4			Current transforme Digital input: 2 poin	its, RSP input, RS-	
							_		485 communication		
							0 D		No additional treatr Inspection certificat		
							H T		Tropicalization trea		
Note 1. A current transformer is sold						K		Anti-sulfide treatme			
separately.  Note 2. When the control output is R1, the							В		Tropicalization trea	tment applied and	
	current applied	. MFB	input i	s appli	ed.		L		Anti-sulfide treatme	ent applied and	
Note 3.	Can no	t be se	lected	for DC	mode	l.	Υ		Inspection certificat Complying with the		
								<u> </u>	certification		
0								IP65 inapplicable			

### **Specifications**

• PV Inputs K.J.E.T.R.S.B.N (JIS C1602-1995) Thermocouple

PL II (Engelhard Industries Data (ITS90)) WRe5-26 (ASTM E988-96(Reapproved 2002))

Ni-NiMo (ASTM E1751-00) PR40-20 (Johnson Matthey Data) DIN U,DIN L (DIN 43710-1985)

Gold iron chromel (Hayashidenko Data)

Resistance temperature detector (RTD): Pt100 (JIS C1604-1997)

JPt100 (JIS C1604-1989)

0 to 10mV, -10 to +10mV, 0 to 100mV, 0 to 1V, 1 to 5V, 0 to 5V, 0 to 10V DC voltage: DC current: 0 to 20mA, 4 to 20mA

100ms ±0.1%FS±1digit, Sampling cycle:

Indication accuracy:

±0.2%FS±1digit for a negative area of the thermocouple (at ambient temperature 23±2°C)

Cold junction compensation accuracy: ±0.5% (at ambient temperature 23±2°C)

±1.0% (at ambient temperature 15 to 35°C) ±1.5% (at ambient temperature 0 to 15 or 35 to 50°C) Cold junction compensation method:

The compensation in the controller or the compensation at the outside of the controller (0°C only) can be selected.

Digital input

Input type: Dry contact or open collector Allowable ON contact resistance:  $Max.250\Omega$ Allowable OFF contact resistance: Min.100k $\Omega$ Allowable ON residual voltage: Max.1.0V

Approx.7.5mA (in case of short circuit). Approx.5.0mA (in case of contact resistance 250Ω) Terminal current (ON):

Minimum hold time:

Current transformer input Number of input points:

Input object:

Current transformer with 100 to 4,000 turns (availability is by 100-turn units)

Optional unit Model No.: QN206A (800 turns, hole diameter: 5.8mm) Optional unit Model No.: QN212A (800 turns, hole diameter: 12mm)

Current measurement 0.4Aac (800 turns, 1 time)

Formula; Number of turns ÷ (2000 x number of power

Current measurement upper limit:

50.0Aac (800 turns, 1 time) Formula; Number of turns ÷ (16 x number of power

wire loops)

Allowable measured 70.0Aac (800 turns, 1 time)

Formula; Number of turns ÷ (16 x number of power

wire loops) x 1.4 0.0Aac

Display range lower

Display range upper 70.0Aac (800 turns, 1 time)

Formula; Number of turns ÷ (16 x number of power wire loops) x 1.4 ±5%FS

Display accuracy: Display resolution 0.1Aac

 Motor feedback potentiom input (R1 model) Allowable resistance: Detection of line break: 100 to 2500Ω

Displays AL07 RSP input linear 0 to 20mA/4 to 20mA or linear 0 to 5V/1 to 5V/ Input type:

0 to 10V Sampling cycle:

Indication accuracy:
Operation at input break: ±0.1%FS±1digit (at ambient temperature 23±2°C) Downscale + AL06

• Control outputs

 Relay output Contact rating:

NO side 250Vac/30Vdc, 3A (resistive load) NC side 250Vac/30Vdc, 1A (resistive load) NO side Min. 50,000 operations NC side Min. 100,000 operations

Min. switching specifications: 5V, 10t Min. open time / close times: 250ms • Motor drive relay output (R1 mode) 5V, 100mA

250Vac 8A (resistive load) Output rating: Min. 120,000 operations 24Vdc, 40mA Min. switching specifications

 Voltage pulse output (for SSR drive)
 Open circuit voltage: 19Vdc±15%
 Internal resistance: 820±0.5% Allowable current: Min OFF time / ON time: Max. 24mAdc Ims when the time proportional cycle time is less than 10s. 250ms when the time proportional cycle time is more than 10s.

· Current output Output type: Allowable load resistance: 0 to 20mAdc or 4 to 20mAdc Max.600 $\Omega$ ±0.1%FS (at ambient temperature 23±2°C)

±1%FS at 0 to 1mA • Voltage output 0 to 5Vdc/1 to 5V or 0 to 10V

Output type: Allowable load resistance: Min. 1000Ω  $\pm 0.1\%$ FS (at ambient temperature 23 $\pm 2^{\circ}$ C)  $\pm 1\%$ FS at 0 to 0.05V Output accuracy

Auxiliary output

Output accuracy:

0 to 20mAdc or 4 to 20mAdc Output type 600\text{Qmax.} \pmu0.1\%FS (at ambient temperature 23\pmu2\colon\text{C}) \pmu1\%FS at 0 to 1mA Allowable load resistance:

Output accuracy:

Voltage output

0 to 5V/1 to 5Vdc or 0 to 10Vdc Min.  $1000\Omega$   $\pm 0.1\%FS$  (at ambient temperature  $23\pm 2^{\circ}C$ )  $\pm 1\%FS$  at 0 to 0.05VOutput type: Allowable load resistance: Output accuracy

• Event relay outputs (ev1 to 3)

250Vac/30Vdc 2A (resistive load) Output rating:

Min. 100,000 operations 5V, 10mA (reference value) Min. switching specifications: RS-485 communication Transmission line: Transmission speed: 4800, 9600, 19200, 38400bps

Communication protocol: CPL and MODBUS conforming Terminating resistor: Environmental conditions Operating conditions

Àmbient temperature: 0 to 50°C (Gang-mounting: 0 to 40°C) 10 to 90%RH (non condensing) Ambient humidity: Rated power supply voltage: AC model 100 to 240Vac, 50/60Hz DC model 24Vac 50/60Hz, 24Vdc

Power supply voltage range: AC model 85 to 264Vac, 50/60±2Hz DC model 21.6 to 26.4Vac 50/60±2Hz, 21.6 to 26.4Vdc · Transport conditions

Do not connect a terminating resistor.

Ambient temperature: Ambient humidity: 10 to 95%RH (non condensing)

 Other specifications Max. 12VA for AC model Max. 12VA for DC model at 24Vac

Max. 8W for DC model at 24Vdc Max. 20ms (AC model)

Non-detected power failure time: No power failure allowed (DC model) Altitude 2000m or less

C35 Approx.250g (with mounting bracket) Mass: C36 Approx.300g (with mounting bracket)

Terminal screw tightening torque: 0.4 to 0.6N·m Applicable standards: EN61010-1, El EN61010-1, EN61326

Overvoltage category: Category II (IEC60364-4-443, IEC60664-1)

Allowable pollution degree: Pollution degree 2

### Accessories and optional parts

Name	Model No.
Mounting bracket	81409654-001(Accessory)
Current transformer	QN206A(5.8mm hole dia.) / QN212A(12mm hole dia.)
Hard cover	81446915-001(for C35) / 81446916-001(for C36)
Soft cover	81441121-001(for C35) / 81441122-001(for C36)
Terminal cover	81446912-001(for C35) / 81446913-001(for C36)

### SDC35/36 List of Parameters

### [List of Operation Displays]

### ■ Operation Displays

Display	Item	Contents	Initial value	User level
Upper display: PV Lower display: SP	SP (Target value)	SP low limit (C07) to SP high limit (C08)	0	0
L5P ( (Display example) Lower display: LSP	LSP No. (1st digit: Value at the right end digit)	1 to LSP system group (C30 Max. 8)	1	0
5Ł. (- (Display example) Lower display: Step remaining time	Step operation remaining time	Setting is disabled. Upper display: The distinction by step No., ramp-up, ramp-down or soak is displayed at the side location of [St.]. Lower display: Displayed by the unit (either one of 0.1s, min.s, or h.min) based on the step operation time unit (C33).	-	0
Upper display: PV Lower display: MV	MV (Manipulated Variable)	-10.0 to +110.0% Setting is disabled in AUTO mode. (Numeric value does not flash.) Setting is enabled in MANUAL mode. (Numeric value flashes.)	_	0
HERE	Heat MV (Manipulated Variable)	Setting is disabled -10.0 to +110.0%	-	0
Cool	Cool MV (Manipulated Variable)			0
Fb	MFB (Motor opening feedback value)	Setting is disabled10.0 to +110.0% For estimation, displayed by flashing in 0.1 to 100.0%.	ı	0
Upper display: PV Rt ( (Display example)	AT progress display (1st digit = Numeric value at right end digit)	Setting is disabled. Except for 0: During execution of AT (Value is decreased.) 0: Completion of AT	_	0
CEI	CT (Current transformer) current value 1	Setting is disabled.	-	0
CFS	CT (Current transformer) current value 2	Setting is disabled.	-	0
El	Internal event 1 main setting	Setting range is different depending on the internal event operation type.	0	0
E 1. Sb	Internal event 1 sub-setting	-1999 to +9999U: Except below. 0 to 9999U: Setting value is an absolute value. -199.9 to +999.9%: For MV.	0	0
Ef (Display example)	Timer remaining time 1	Setting is disabled. Upper display: The distinction by ON delay or OFF delay is displayed at the side location of [11.]. Lower display: Displayed by the unit (either one of 0.1s, s, or min) based on the internal event 1 delay time unit (E1. the 3rd digit of C3).	-	0
ES.	Internal event 2 main setting	Setting range is different depending on the internal event operation type.	0	0
E2. Sb	Internal event 2 sub-setting	-1999 to +9999U: Except below. 0 to 9999U: Setting value is an absolute value. -199.9 to +999.9%: For MV.	0	0
E2 (Display example)	Timer remaining time 2	Setting is disabled. Upper display: The distinction by ON delay or OFF delay is displayed at the side location of [t2.]. Lower display: Displayed by the unit (either one of 0.1s, s, or min) based on the internal event 2 delay time unit (£2. the 3rd digit of C3).	_	0
8	Internal event 3 main setting	Setting range is different depending on the internal event operation type.	0	0
E3. 5b	Internal event 3 sub-setting	-1999 to +9999U: Except below. 0 to 9999U: Setting value is an absolute value. -199.9 to +999.9%: For MV.	0	0
E3 (Display example)	Timer remaining time 3	Setting is disabled. Upper display: The distinction by ON delay or OFF delay is displayed at the side location of [13.]. Lower display: Displayed by the unit (either one of 0.1s, s, or min) based on the internal event 3 delay time unit(E3. the 3rd digit of C3).	_	0

### [List of Parameter Setting Displays]

### ■ Mode bank

Bank selection: ก็อฮ่ร็

Display	Item	Contents	Initial value	User level
8ñ	AUTO/MANUAL mode selection	ลียะอ : AUTO mode อัลิอ : MANUAL mode	AUTO	0
rr	RUN/READY mode selection	รปก : RUN mode รป๋ัว : READY mode	RUN	0
Lr	LSP/RSP mode selection	L5P : LSP mode r5P : RSP mode	LSP	0
At	AT Stop/Start selection	ጸե. oF : AT Stop ጸե. on : AT Start	AT Stop	0
do.lt	Release all DO latches	Lt. on: Latch continue Lt. of: Latch release	Latch continue	0
C. d) I	Communication DI 1	dl. of : OFF dl. on : ON	OFF	0

### ■ SP bank

Bank selection: 5P

Display	Item	Contents	Initial	User
-19			value	level
-5P	RSP	Setting is disabled.	-	0
Pld. r	PID group No.	1 to 8	1	1
5P - 1 to 5P - 8	SP of LSP1 group to SP of LSP8 group	SP low limit (C07) to SP high limit (C08)	0	0
일년. ( to 일년. 8	PID group No. (for LSP1 to 8)	1 to 8	1	1
-ĀP. l to -ĀP. 8	Ramp (for LSP1 to 8)	to 9999 (The decimal point position is determined by the PV decimal point position and the SP ramp unit.)	0	1
tiñ. I to tiñ. 8	Time (for LSP1 to 8)	0.0 to 999.9 (when step operation time unit is 0.1s.) 0 to 9999 (when step operation time unit is 1s or	0	1

0: Display in basic/standard/high function, 1: Display in standard/high function, User level details

2: Display in high function.

Initial value may vary depending on model No.

### ■ Event bank

Bank selection: Eu

Display	Item	Contents	Initial value	User level
E! to E8	Internal event 1 to 8, main setting	-1999 to +9999 The decimal point position varies by meeting the	0	0
E I. Sb to E8. Sb	Internal event 1 to 8, sub-setting	internal event operation type. 0 to 9999 for some operation type.	0	0
E 1. HY to E8. HY	Internal event 1 to 8, hysteresis	0 to 9999 The decimal point position varies by meeting the internal event operation type.	5	0
E1. on to E8. on	Internal event 1 to 8, ON delay	0.0 to 999.9 (For the delay time unit 0.1s)	0	2
E1. oF to E8. oF	Internal event 1 to 8, OFF delay	0 to 9999 (Except for the delay time unit 0.1s)	0	2

### ■ PID bank

Bank selection: ೭/ರ

Display	Item	Contents	Initial value	User level
P-1 to P-8	Proportional band (PID1 to 8 group)	0.1 to 999.9%	5.0	0
;- ; to ;-8	Integration time (PID1 to 8 group)	0 to 9999s or 0.0 to 999.9s (0: No integral control action)	120	0
ฮ-¦ to ฮ-8	Derivative time (PID1 to 8 group)	0 to 9999s or 0.0 to 999.9s (0: No derivative control action)	30	0
rE-1 to rE-8	Manual reset (PID1 to 8 group)	-10.0 to +110.0%	50.0	0
oL-1 to oL-8	MV low limit (PID1 to 8 group)	-10.0 to +110.0%	0.0	1
οΗ-1 to οΗ-8	MV high limit (PID1 to 8group)	-10.0 to +110.0%	100.0	1
P-10 to P-80	Cool-side proportional band (PID1 to 8 group)	0.1 to 999.9%	5.0	0
1-10 to 1-80	Cool-side integration time (PID1 to 8 group)	0 to 9999s or 0.0 to 999.9s (0: No integral control action)	120	0
d-10 to d-80	Cool-side derivative time (PID1 to 8 group)	0 to 9999s or 0.0 to 999.9s (0: No derivative control action)	30	0
oL10 to oL80	Cool-side MV low limit (PID1 to 8 group)	-10.0 to +110.0%	0.0	1
оН. I С to оН. В С	Cool-side MV high limit (PID1 to 8 group)	-10.0 to +110.0%	100.0	1

### ■ Parameter bank Bank selection: PR-R

Display	Item	Contents	Initial	User
			value	level
CErL	Control method	0: ON/OFF control 1: PID fixed	0 or 1	0
Rt. ol	MV low limit at AT	-10.0 to +110.0%	0.0	0
Rt. oH	MV high limit at AT	-10.0 to +110.0%	100.0	0
dlFF	ON/OFF control differential	0 to 9999U	5	0
oFF5	ON/OFF control operating point offset	-1999 to 9999U	0	2
FL	PV filter	0.0 to 120.0s	0.0	0
rR	PV ratio	0.001 to 9.999	1.000	1
ы	PV bias	-1999 to +9999U	0	0
FLE	RSP filter	0.0 to 120.0s	0.0	0
r82	RSP ratio	0.001 to 9.999	1.000	1
PIS.	RSP bias	-1999 to +9999U	0	0
CYU	Time proportional cycle unit 1	0: 1s unit 1: 0.5s fixed (Cycle time is disabled.) 2: 0.2s fixed (Cycle time is disabled.) 3: 0.1s fixed (Cycle time is disabled.)	0	2
CY	Time proportional cycle1	5 to 120s (*1) 1 to 120s (*2)	10 or 2	0
CANS	Time proportional cycle unit 2	0: 1s unit 1: 0.5s fixed (Cycle time is disabled.) 2: 0.2s fixed (Cycle time is disabled.) 3: 0.1s fixed (Cycle time is disabled.)	0	2
CAS	Time proportional cycle 2	5 to 120s (*1) 1 to 120s (*2)	10 or 2	0
EP. EY	Time proportional operation type	Controllability aiming type     Actuator life aiming type     (Only one ON/OFF operation within time proportional cycle time)	0 or 1	2
oUEL	MV variation limit	0.0 to 999.9%/s (0.0: No limit)	0.0	2
SPU	SP ramp-up	0.0 to 999.9U (0.0: No ramp)	0.0	2
SPd	SP ramp-down		0.0	2

<sup>\*1</sup> When the output includes the relay ouput.
\*2 When the output does not include the relay output.

### ■ Extension tuning bank Bank selection: Et

	0100110111122			
Display	Item	Contents	Initial	User
			value	level
RE. ES	AT type	O: Normal (Standard control characteristicis)     I: Immediate response (Control characteristicis immediately responding to the external disturbance.)     Stable (Control characteristics with less up/down function of PV)	1	0
dF. bd	Just-FiTTER setting band	0.00 to 10.00	0.30	2
SP. L9	SP lag constant	0.0 to 999.9	0.0	2
RE-P	AT proportional band tuning factor	0.00 to 99.99	1.00	2
RE-I	AT integration time tuning factor	0.00 to 99.99	1.00	2
At-d	AT derivative time tuning factor	0.00 to 99.99	(Note)	2
Ctr. A	Control algorithm	0: PID (conventional PID) 1: RationaLOOP (high performance type)	0	1
dF. ou	Just-FiTTER overshoot suppression factor	0 to 100	0	1

(Note) Position proportional control model: 0.00, Nonposition propor. types: 1.00

#### ■ Zone bank Bank selection: ≥onE

Initial User value level Displayed when the zone PID operation is used (C24≠0).

### [List of Setup Setting Displays]

### ■ Setup bank

Display	Item	Contents	Initial value	User
C 0 1	PV input range	Thermocouple: 1 to 26	88	0
	type	RTD: 41 to 68		
C 08	Temperature unit	DC current/voltage: 81 to 84, 86 to 90 0: Centigrade (°C)	0	0
C 03	Cold junction	Fahrenheit (°F)     Cold junction compensation is performed. (Internal)	0	2
. 03	compensation (T/C)	Cold junction compensation is performed. (Internal)     Cold junction compensation is not performed.     (External)	U	2
C 04	Decimal point position	0: No decimal point 1: One digit after decimal point	0	0
	position	2: Two digits after decimal point		
		3: Three digits after decimal point (Select '0' or '1' for the thermocouple/RTD range		
		with decimal point)		
C 05	PV range low limit	When the PV input range type is thermocouple or RTD, the setting is disabled although range low limit is	0	0
		displayed1999 to +9999U when the PV input range		
C 06	PV range high limit	type is DC voltage/current.  When the PV input range type is thermocouple or	1000	0
		RTD, the setting is disabled although range high limit		_
		is displayed. –1999 to +9999U when the PV input range type is DC voltage/current.		
C 07	SP low limit	PV input range low limit to PV input range high limit	0	1
C 08 C 09	SP high limit Squarer root	0.0 to 100.0%	1000	1 2
	extraction dropout	(0.0: No square root extraction)		
C 10	RSP range type	0: 4 to 20mA 1: 0 to 20mA	0	0
		2: 0 to 5V		
		3: 1 to 5V 4: 0 to 10V		
CII	RSP range low	-1999 to +9999U	0	0
C 18	limit		1000	0
r 16	RSP range high limit		1000	U
CH	Control action (direct/reverse)	0: Heat control (reverse action) 1: Cool control (direct action)	0	0
C 15	Selection of MV	Control operation is continued.	0	2
	at PV alarm occurrence	1: MV at PV alarm occurrence is outputted.		
C 16	MV at PV alarm	-10.0 to +110.0%	0.0	2
	occurrence	10.01		
cn	MV at READY (at heat-side for	-10.0 to +110.0%	0.0	1
C 10	heat/cool control)	10.01		
C 18	MV at READY (at cool-side)	-10.0 to +110.0%	0.0	1
C 19	Operation at	0: Bump-less	0	1
C 80	MANUAL change Preset MANUAL	1: Preset -10.0 to +110.0%	0.0 or	1
	value	(Used even at MANUAL mode when power is ON.)	50.0	
651	PID operation initialization	0: Automatic 1: Not initialized	0	2
	function selection	2: Initialized (when SP value different from current		
C 55.3	PID operation	value is inputted.) -10.0 to +110.0%	0.0 or	2
C 23	initial MV	O. No designal point	50.0	0
. 63	Control parameter decimal point	No decimal point     One digit after decimal point (Decimal point of	0	2
C 24	Zone PID action	integration time or derivative time)  0: Disabled	0	2
. (1	selection	1: Selection by SP	U	2
c 3c	Heatler deserted	2: Selection by PV		0
C 26	Heat/cool control selection	0: Disabled. 1: Enabled.	0	0
ट श	Heat/cool selection	0: Normal	0	1
C 28	Dead zone	1: Energy saving -100.0 to +100.0%	0.0	0
C 29	Heat/cool control	-10.0 to +110.0%	50.0	2
C 30	selection point LSP setting	1 to 8	1	0
	system		·	
C31	SP ramp type	0: Standard 1: Multi-ramp	0	2
		2: Step operation. Step is stopped when power is		
		re-supplied. (READY) 3: Step operation. Step is recovered when power is		
		re-supplied.		
C 32	SP ramp unit	0: 0.1U/s 1: 0.1U/min	1	2
		2: 0.1U/h		
C 33	Step operation time unit	0: 0.1s 1: 1s (Displayed in min.s in console.)	0	2
		2: 1min (Displayed in h.min in console.)		
C 34	Step operation	0: Disabled. 1: Enabled.	0	2
C 35	PV start Step operation	0: Stop (Not looped.)	0	2
	loop	1: Looped.		
C 36	CT1 operation	Final step continued. (Not looped.)     Heater burnout detection	0	0
	type	1: Current value measurement		
C 37	CT1 output	0: Control output 1 1: Control output 2	0	0
		2: Event output 1		
		3: Event output 2 4: Event output 3		
C 38	CT1 measurement	30 to 300ms	30	0
C 39	wait time CT2 operation	Same as CT1.	0	0

Display	Item	Contents	Initial value	User
C40 C41	CT2 output CT2 measurement	Same as CT1.	30	0
C 45	wait time  Control output 1	Current output:	1	0
- 112	range	1: 4 to 2mA 2: 0 to 20mA	'	0
		Continuous voltage output: 1: 1 to 5V		
		2: 0 to 5V 3: 0 to 10V		
C 43	Control output 1	0: MV	0	0
	type	1: Heat MV (for heat/cool control) 2: Cool MV (for heat/cool control)		
		3: PV 4: PV before ratio bias filter		
		5: SP 6: Deviation (PV-SP)		
		7: CT1 current value 8: CT2 current value		
		9: MFB (Including estimation MFB) 10: SP+MV		
<u> </u>	Control output 1	11: PV+MV -1999 to +9999	0.0	0
C 45	scaling low limit Control output 1	(The decimal point position and unit may vary depending on the control output 1 type.)	100.0	0
C 46	scaling high limit Control output 1	0 to 9999	200	0
C 47	MV scalable bandwidth	(Available when control output 1 type is 10 or 11.)		
	Control output 2 range type	Same as control output 1.	1	0
C 48	Control output 2 type		3	0
( 49	Control output 2 scaling low limit	-1999 to +9999 (The decimal point position and unit may vary	0	0
C 50	Control output 2 scaling high limit	depending on the control output 2 type.)	1000	0
C 5 1	Control output 2 MV scalable bandwidth	0 to 9999 (Available when control output 2 type is 10 or 11.)	200	0
C 52	Auxiliary output range	Same as control output 1.	1	0
C 53	Auxiliary output		3	0
C SY	Auxiliary output	-1999 to +9999	0	0
C 55	scaling low limit Auxiliary output	(The decimal point position and unit may vary depending on the auxiliary output type.)	1000	0
C 56	scaling high limit Auxiliary output	0 to 9999	200	0
C 57	MV scalable bandwidth Position	(Available when auxiliary output type is 10 or 11.)  0: MFB control + estimated position control	0	0
	proportional control method	MFB control     Estimated position control (MFB disabled)		
	selection	Estimated position control (MFB disabled) +     position adjustment at power supply ON		
C 58	Position proportional	0.5 to 25.0%	10.0	0
C 59	control dead zone Position	O. Ozakallahilik, ziminakan	1	0
L 34	proportional	Controllability aiming type     Potentiometer life aiming type	'	U
C 60	control long life Position	0: Stop	0	0
	proportional control tuning start	1: Start		
C 6 1	Position proportional full-	0 to 9999	1000	0
C 62	close tuning value Position	0 to 9999	3000	0
	proportional full- open tuning value			
C 63	Position proportional full-	5.0 to 240.0s	30.0	0
C 64	open time  Communication	0: CPL	0	0
	type	1: MODBUS ASCII format 2: MODBUS RTU format	"	U
C 65	Station address	0 to 127	0	0
C 66	Transmission	(Communication is disabled when "0" is set.)  0: 4800bps	2	0
	speed	1: 9600bps 2: 19200bps		
C 67	Data format (data	3: 38400bps 0: 7bit	1	0
C 68	length)  Data format	1: 8bit 0: Even parity	0	0
	(parity)	1: Odd parity 2: No parity		
C 69	Data format (stop	0: 1bit 1: 2bits	0	0
C 70	Communication minimum response	1 to 250ms	3	2
<del>[]</del>	time  Key operation	0: Standard type	0	2
	mode/type	1: Special type		
C 72	Mode key function	0: Invalid 1: AUTO/MANUAL selection	1	0
		2: RUN/READY selection 3: AT Stop/Start		
		4: LSP group selection 5: Release of all DO latches		
		6: LSP/RSP selection 7: Communication DI1 selection		
C 13	Mode display	8: Invalid Whether the mode bank setup display is enabled or	255	1
	setup	disabled is determined by the sum of the following weighting:		
		Bit 0: AUTO/MANUAL display 0: Disabled, +1: Enabled		
		Bit 1: RUN/READY display		
		0: Disabled, +2: Enabled Bit 2: LSP/RSP display		
		0: Disabled, +4: Enabled Bit 3: AT stop/start display		
		0: Disabled, +8: Enabled Bit 4: DO latch release		
		0: Disabled, +16: Enabled Bit 5: Communication DI1 ON/OFF display		
		0: Disabled, +32: Enabled Other invalid setup: 0, +64, +128		
	1		1	

(continued on back page)

CP-UM-5289JE

E3

Βιοριαγ	item	Contonio	value	level
ርዝ	PV/SP value display setup	Whether the basic display is enabled or disabled is determined by the sum of the following weighting: Bit 0: PV display 0: Disabled, +1: Enabled Bit 1: SP display	15	1
		0: Disabled, +2: Enabled Bit 2: LSP group No. display 0: Disabled, +4: Enabled Other invalid setup: 0, +8		
C 75	MV display setup	Whether the basic display is enabled or disabled is determined by the sum of the following weighting: Bit 0: MV display 0: Disabled, +1: Enabled Bit 1: Heat MV:cool MV display 0: Disabled, +2: Enabled Bit 2: MFB display 0: Disabled, +4: Enabled Bit 3: AT progress display	15	1
C 76	Event setting value display setup	O: Disabled, +8: Enabled O: In the operation display mode, the internal event setting value is not displayed.  1: In the operation display mode, the internal event 1 setting value is displayed.  2: In the operation display mode, the internal event 1 to 2 setting value is displayed.  3: In the operation display mode, the internal event 1 to 3 setting value is displayed.	0	1
cn	Event remaining time display setup	In the operation display mode, the ON/OFF delay remaining time of the internal event is not displayed.     In the operation display mode, the ON/OFF delay remaining time of the internal event 1 is displayed.     In the operation display mode, the ON/OFF delay remaining time of the internal event 1 to 2 is displayed.     In the operation display mode, the ON/OFF delay remaining time of the internal event 1 to 3 is	0	1
C 78	CT input current value display setup	displayed.  o: In the operation display mode, the CT current value is not displayed.  1: In the operation display mode, the CT1 current value is displayed.  2: In the operation display mode, the CT1 to 2	0	1
C79	User level	current value is displayed.  0: Basic configuration  1: Standard configuration  2: High function configuration	1	0
₹ 80	LED monitor	Disabled     Disabled	0	2
C 81	MS indicating lamp ON condition (1st priority)	O: Normally open (Normally OFF=0) 1: Normally close (Normally ON=1) 2 to 9: Internal event 1 to 8 10 to 13: Undefined 14:MY1 (ON/OFF, time proportional 1, heat-side, OPEN-side output) 15: MV2 (time proportional 2, cool-side, CLOSE-side output) 16 to 17: Undefined 18 to 21: DI1 to DI4 22 to 25: Undefined 26 to 30: Internal contact 1 to 5 31 to 33: Undefined 34 to 37: Communication DI1 to DI4 38:MANUAL 39:READY 40:RSP 41:AT 42:During ramp 43:Undefined 44:Alarm 45:PV alarm 46:Undefined 47:Mode key function selection status 48:Event output 1 status 49:Control output 1 status	39	2
₹82	MS indicating lamp ON status (1st priority)	0: Lif  : Slow flashing 2: 2 times flashing 3: Fast flashing 4: Left → Bight 5: Right → Left 6: Right to left going and returning 7: Deviation OK 8: Deviation graph 9: MV graph 10: Heat-side MV graph 11: Cool-side MV graph 12: MFB graph 13: D1 monitor 14: Internal contact monitor	1	2
€ 83	MS indicating lamp ON condition (2nd priority)	Same as MS indicating lamp ON condition (1st priority)	44	2
C 84	MS indicating lamp ON status (2nd priority)	Same as MS indicating lamp ON status (1st priority)	6	2
C 85	MS indicating lamp ON condition (3rd priority)	Same as MS indicating lamp ON condition (1st priority)	1	2
C 86	MS indicating lamp ON status (3rd priority)	Same as MS indicating lamp ON status (1st priority)	9	2
C 87	MS indicating lamp deviation range	0 to 9999U	5	2
C 88	Special function	0 to 15 (0 at power supply ON.)	0	2
C 89	Zener barrier adjustment	Rewriting by adjustment is enabled.  Numerical value inputting manually is disabled	0.00	2
C 90	CT1 number of winding	0: turns 1 to 40: Setting value multiplied by one hundred becomes number of winding.	8	2
(91	CT1 number of	0: 1time 1 to 6: number of times	1	2

Display	Item	Contents	Initial value	User level
C 92	CT2 number of winding	800 turns     1 to 40: Setting value multiplied by one hundred becomes number of winding.	8	2
( 93	CT2 number of power wire loops	0: 1time 1 to 6: number of times	1	2

## ■ Event assignment bank

Bank selection: *E⊍€F* 

Display	Item	Contents	Initial	User
5151			value	level
E1.C1 to E8.C1	Operation type of internal event 1 to 8 Configuration 1 Operation type	0: No event 1: PV high limit 2: PV low limit 3: PV high/low limit 4: Deviation high limit 5: Deviation high limit 5: Deviation high limit 6: Deviation high/low limit 7: Deviation high/low limit (Final SP reference) 10: SP high limit 11: SP low limit 12: SP high/low limit 12: SP high/low limit 13: MV high limit 14: MV low limit 15: MV high limit 16: CTI heater short-circuit 16: CTI heater short-circuit 17: CTI heater short-circuit 19: CT2 heater short-circuit 19: CT2 heater short-circuit 19: CT2 heater short-circuit 20: Loop diagnosis 1 21: Loop diagnosis 2 22: Loop diagnosis 3 23: Alarm (status) 24: READY (status) 25: MANUAL (status) 26: RSP (status) 27: During AT execution (status) 28: During SP ramp (status) 30: Invalid 31: During motor opening estimation (status) 32: Timer (status) 33: MFB high/low limit	0	0
E1.C2 to E8.C2	Internal event 1 to 8 Configuration 2 Tst digit: Direct /Reverse 2nd digit: Stand-by  Grd digit: SVENT state at READY 4th digit: Undefined	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.  0: Direct 1: Reverse 0: None 1: Standby 2: Standby + Standby at SP change 0: Continue 1: Forced OFF	0000	0
E1.C3 to E8.C3	Internal event 1 to 8 Configuration 3 1st digit: Alarm OR  2nd digit: Special OFF 3rd digit: Delay time unit  4th digit: Undefined	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.  0: No event 1: Alarm direct + OR operation 2: Alarm direct + AND operation 3: Alarm reverse + OR operation 4: Alarm reverse + AND operation 0: As normal execution 1: Event OFF at the event setting value (main)=0 0: 0.1s 1: 1s 2: 1min	0000	2

### ■ DI assignment bank Bank selection:

Display	Item	Contents	Initial	User
			value	level
dii.i to dis.i	Internal contact 1 to 5 Operation type	O: No function I: LSP group selection (0/+1) 2: LSP group selection (0/+2) 3: LSP group selection (0/+4) 4: PID group selection (0/+4) 5: PID group selection (0/+1) 5: PID group selection (0/+2) 6: PID group selection (0/+2) 6: PID group selection (0/+4) 7: RUN/READY selection 8: AUTO/MANUAL selection 9: LSP/RSP selection 10: AT Stop/Start 11: Invalid 12: Control action direct/reverse selection (As per setting/opposite operation of setting) 13: SP ramp Enabled/Disabled 14: PV Hold (No-hold/Hold) 15: PV maximum value hold (No-hold/Hold) 16: PV minimum value hold (No-hold/Hold) 17: Timer Stop/Start 18: Release of all DO latches (Continue/Release) 19: Advance (No advance/Advance) 20: Step hold (No hold/Hold)	0	0
<i>dl</i> 1. ∂ to <i>dl</i> 5. ∂	Internal contact 1 to 5 Input bit operation	0: Disabled. (Input of default) 1: Function 1 ((A and B) or (C and D)) 2: Function 2 ((A or B) and (C or D)) 3: Function 3 (A or B or C or D) 4: Function 4 (A and B and C and D)	0	2

Display	Item	Contents	Initial value	User level
<i>d</i> 11.3 to <i>d</i> 15.3	Internal contact 1 to 5 Input assignment A	0: Normally open (OFF, 0) 1: Normally close (ON, 1) 2: D11 3: D12 4: D13 5: D14 6 to 9: Undefined 10: Internal event 1	2 to 5 or 0	2
<i>8</i> 11.4 to <i>8</i> 15.4	Internal contact 1 to 5 Input assignment B	11: Internal event 2 12: Internal event 3 13: Internal event 4 14: Internal event 5 15: Internal event 6 16: Internal event 7 17: Internal event 8	0	2
d11, 5 to d15, 5	Internal contact 1 to 5 Input assignment C	18: Communication DI1 19: Communication DI2 20: Communication DI3 21: Communication DI4 22: MANUAL mode 23: READY mode 24: RSP mode 25: During AT execution 26: During SP ramp	0	2
d) 1, 6 to d) 5, 6	Internal contact 1 to 5 Input assignment D	27: Undefined 28: Alarm is enabled.	0	2
dll. 7 to dl5. 7	Internal contact 1 to 5 Polarity A to D 1st digit: Polarity A (Polarity of input assignment A) 2nd digit: Polarity B (Polarity of input assignment B) 3rd digit: Polarity C (Polarity of input assignment C) 4th digit: Polarity C (Polarity of input assignment C)	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.  0: Direct 1: Reverse	0000	2
d) l. 8 to d) 5. 8	Internal contact 1 to 5 Polarity	0: Direct 1: Reverse	0	2
<i>dl1.</i> 9 to <i>dl5.</i> 9	Internal contact 1 to 5 Internal event No.assignment	0: Every internal event 1 to 8: Internal event numbers	0	2

### ■ DO assignment bank Bank selection: do

Display	Item	Contents	Initial value	User level
obl.! to ob2.! Eul.! to Eu3.!	Control output 1 to 2, event output 1 to 3 Operation type	C: Input of default     MY1 (ON/OFF control output, time proportional output, heat-side proportional output of heat/cool control)     MY2 (cool-side proportional output of heat/cool control)     S: Function 1 ((A and B) or (C and D))     Function 2 ((A or B) and (C or D))     Function 3 (A or B or C or D)     For Cool of C or D)     Function 4 (A and B and C and D)	0	2
obl. 2 to obl. 2 Eul. 2 to Eul. 3	Control output 1 to 2, event output 1 to 3 Output assignment A	0: Normally open (OFF, 0) 1: Normally close (ON, 1) 2: Internal event 1	14 to 15 or 2 to 4	2
o£ (, 3 to o&2, 3 Eu (, 3 to Eu 3, 3	Control output 1 to 2, event output 1 to 3 Output assignment B	10 to 13: Undefined 14: MV1 15: MV2 16 to 17: Undefined 18: DI1 19: DI2 20: DI3 21: DI4 22 to 25: Undefined 26: Internal contact 1	0	2
oE !. Y to oE 2. Y Eu !. Y to Eu 3. Y	Control output 1 to 2, event output 1 to 3 Output assignment C	27: Internal contact 2 28: Internal contact 3 29: Internal contact 4	0	2
oΕ4.5 to oΕ2.5 Eυ4.5 to Eυ3.5	Control output 1 to 2, event output 1 to 3 output 1 to 3 Output assignment D	99: READY mode 40: RSP mode 41: During AT execution 42: During SP ramp 43: Undefined 44: Alarm is enabled. 45: PV alarm is enabled. 46: Undefined 47: Mode key function selection status 48: Event output 1 status 49: Control output 1 status	0	2

Display	Item	Contents	Initial value	User level
οξί, δ to οξέ, δ Ευί, δ to Ευί, δ	Control output 1 to 2, event output 1 to 3 Polality A to D	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.	0000	2
	1st digit: Polarity A 2nd digit: Polarity B 3rd digit: Polarity C 4th digit: Polarity D	0: Direct 1: Reverse	0 0 0	
o£1.7 to o£2.7 Eu1.7 to Eu3.7	Control output 1 to 2, event output 1 to 3 Polarity	0: Direct 1: Reverse	0	2
οξί.8 to οξ2.8 Ευί.8 to Ευ3.8	Control output 1 to 2, event output 1 to 3 Latch	Disabled     Enabled (Latch at ON)     Enabled (Latch at OFF, except at the time of initialization after power ON)	0	2

### ■ User function bank Bank selection: $\mathcal{G}^{\mathcal{F}}$

Display	Item	Contents	Initial value	User level
UF - 1	User function definition 1	This is the display in upper display. The setup exception is as follows:		1
UF-2	User function definition 2	P: Yet to be registered. P: Proportional band of the PID group in use I: Integration time of the PID group in use		1
UF-3	User function definition 3	d: Derivative time of the PID group in use r \xi - \cdot : Manual reset of the PID group in use		1
UF-4	User function definition 4	oL: MV low limit of the PID group in use oH: MV high limit of the PID group in use		1
UF-S	User function definition 5	P£: Cool-side proportional band of the PID group in use  I£: Cool-side integration time of the PID group		1
UF-6	User function definition 6	in use  d € : Cool-side derivative time of the PID group		1
UF-7	User function definition 7	in use  oL_£: Cool-side MV low limit of the PID group in  use		1
UF-8	User function definition 8	oHC: Cool-side of MV high limit of the PID group in use		1

### ■ Lock bank

Bank selection: LoC

Display	Item	Contents	Initial value	User
LoC	Key lock	O: All settings are enabled. 1: Mode, event, operation display, SP, UF, lock, manual MV, and mode key can be set. 2: Operation display, SP, UF, lock, manual MV, and mode key can be set. 3: UF, lock, manual MV, and mode key can be set.	0	0
C. LoC	Communication lock	RS-485 communication read/write is enabled.     RS-485 communication read/write is disabled.	0	2
L. LoC	Loader lock	Coader communication read/write is enabled.     Loader communication read/write is disabled.	0	2
PRSS	Password display	0 to 15 5: Password 1A to 2B display	0	0
PS IR	Password 1A	0000 to FFFF (hexadecimal value)	0000	0
PSER	Password 2A	0000 to FFFF (hexadecimal value)	0000	0
PS 16	Password 1B	0000 to FFFF (hexadecimal value)	0000	0
PS2b	Password 2B	0000 to FFFF (hexadecimal value)	0000	0

### ■ Instrument information bank Bank selection: /ಡ

Display	Item	Contents	Initial value	User level
1801	ROM ID	2 fixed	_	2
1808	ROM version 1	XX. XX (2 digits after decimal point)	_	2
1603	ROM version 2	XX. XX (2 digits after decimal point)	_	2
1804	SLP support Information		_	2
1805	EST support version		_	2
1806	Manufacturing date code (year)	Year-2000. Ex.: "3" means the year 2003.	_	2
1801	Manufacturing date code (month, day)	Month + Day ÷ 100 Ex.: "12.01" means the 1st day of December	_	2
1608	Serial No.		_	2

### azbil

Specifications are subject to change without notice.

Yamatake Corporation Advanced Automation Company

1-12-2 Kawana, Fujisawa Kanagawa 251-8522 Japan

Printed in Japan. 1st Edition: Issued in Oct. 2003 (A) 15th Edition: Issued in Mar. 2008 (B)

URL: http://www.azbil.com Printed on recycled paper. (07)

E4